

2008 Atlas Copco H1257 Simba PD03



Make	Atlas Copco			Model	H1257 Simba		
Year	2008	Hours	2074			As at	01/09/2018
Mileage					km	As at	
Serial/VIN	AVO08A444, 89917557				Engine Serial		
Details	2008 Atlas Copco H1257 Simba PD03. YOM 2008 Serial no AVO08A444, 89917557 Frame Hours estimated at 2074. Lot 0372 offered running to drive on to buyers transport. Sold via Online Auction ex Kambalda Western Australia.						
Asking price	AUD	Under review - call for pricing					
Ex site	Australia, Western Australia, Kambalda						

Service history	Poor condition 8923 percussion hours
------------------------	---

**For further details, to make an offer or book an inspection, contact
Global Equipment Solutions on Office: 08 9201 1142**









Plant No	Date	Work Order	W/Ord Description	Work Type	History Notes	SMU Readings
PD03	16/12/2014	200847	Cylinder - Feed Thrust Changeout	Component Change out	16/12/14 6-9.30 Replaced cylinder & sent to AT	1866 HR, 7996 LP
PD03	18/12/2014	200898	Pito Cylinder Change out	Component Change out	Cylinder to be sent to Centre engineering	1870 HR, 8000 LP
PD03	22/02/2015	201980	Pito Cylinder Change out on condition	Component Change out		1916 HR, 8284 LP
PD03	4/03/2015	202093	Pito Cylinder Change out on condition	Component Change out		1924 HR, 8342 LP
PD03	28/04/2015	203092	Cylinder - RH Front Jack Leg Change out on cond	Component Change out		1977 HR
PD03	12/05/2015	203497	Cylinder - RH Rear Jack Leg Changeout on condit	Component Change out		1992 HR
PD03	19/06/2015	204246	Cylinder - LH Front Jack Leg Change out on condi	Component Change out		2032 HR, 8808 LP
PD03	13/10/2016	226139	Cylinder - Rod Handler Arms Changeout on condi	Component Change out	Replaced Both Rod Handlers worn out !	2128 HR, 9260 LP
PD03	19/01/2018	235523	Cylinder - Feed Thrust Changeout on condition	Component Change out		2315 HR, 455 LP
PD03	16/04/2018	237126	Cylinder - Feed Extension Changeout (On Conditio	Component Change out		

Plant No	Date	Work Order	W/Ord Description	Work Type	History Notes	SMU Readings
PD03	1/01/2014	122397	Blown Hose.MEMS W/O 122397	Breakdown		
PD03	1/01/2014	122412	Daily Service adjust dampning pressure.MEMS W/O 122412	Preventative Maintenance		
PD03	2/01/2014	122445	D/S,bolt and align rod grippers,repair smashed drifter	Breakdown		1531 HR, 6615 LP
PD03	4/01/2014	122498	Daily Service, replace all drifter hoses.MEMS W/O 122498	Preventative Maintenance		1532 HR, 6633 LP
PD03	4/01/2014	122490	Repir's requested from operator.MEMS W/O 122490	Corrective Maintenance		1532 HR, 6633 LP
PD03	5/01/2014	122545	Daily service, hang and tidy loom.MEMS W/O 122545	Preventative Maintenance		6637 LP
PD03	5/01/2014	122525	Daily service, replaced doudy seal on rear stinger	Preventative Maintenance		6637 LP
PD03	8/01/2014	122650	2 Weekly Service. Air tap at the rear of the rig	Preventative Maintenance		1534 HR, 6639 LP
PD03	12/01/2014	122808	Weld up stinger extension, test turning device, fit	Breakdown		6658 LP
PD03	13/01/2014	122851	Daily Service, oil coming out of flushing head, re	Breakdown		6661 LP
PD03	14/01/2014	122868	c/o mux section of Drifter, straighten out frontce	Breakdown		1540 HR, 6662 LP
PD03	14/01/2014	122886	Straighten front centraliser, fit to rail, heli coil rail	Breakdown		1540 HR, 6662 LP
PD03	15/01/2014	122916	Daily Service & replaced Pos 2 jack leg & fitted pi	Breakdown		1541 HR, 6662 LP
PD03	15/01/2014	122913	Daily Service, rear plate bolts pulled out.MEMS W/O 122913	Preventative Maintenance		1541 HR, 6662 LP
PD03	16/01/2014	122969	Daily Service & inspect compressor (U/S)MEMS W/O 122969	Breakdown		1542 HR, 6662 LP
PD03	17/01/2014	123009	Accumulator, boom movement fault & water in th	Breakdown		1544 HR, 6671 LP
PD03	17/01/2014	123022	Daily Service, disconnect us compressor.MEMS W/O 123022	Preventative Maintenance		1544 HR, 6671 LP
PD03	18/01/2014	122980	C/O ramp p coil and spool.MEMS W/O 122980	Breakdown		6673 LP
PD03	18/01/2014	122995	C/O us water tap, check valve, us pitto cylinder, -	Breakdown		6673 LP
PD03	19/01/2014	123039	Check air receiver for water.MEMS W/O 123039	Corrective Maintenance		1546 HR, 6676 LP
PD03	19/01/2014	123071	Daily Service, adjust rod handler.MEMS W/O 123071	Preventative Maintenance		1546 HR, 6676 LP
PD03	20/01/2014	123082	Daily Service & adjust rod handlersMEMS W/O 123082	Breakdown		6681 LP
PD03	20/01/2014	123091	Daily Service, air reciever tank had water in it dra	Breakdown		6681 LP
PD03	21/01/2014	123122	Start fault, green death in fire sup boxMEMS W/O 123122	Breakdown		1547 HR, 6685 LP
PD03	22/01/2014	123145	2 Weekly Service. Test check cable reel limt is w	Preventative Maintenance		6689 LP
PD03	22/01/2014	123158	Finish fitting steering cylinderMEMS W/O 123158	Corrective Maintenance		6689 LP
PD03	22/01/2014	123153	Kick out fault Air turned offMEMS W/O 123153	Breakdown		6689 LP
PD03	23/01/2014	123173	Replaced ignition barrel (siezed), fit keeper plate	Breakdown		6692 LP
PD03	24/01/2014	123223	Daily service, had start fault , secure hose on reel	Preventative Maintenance		1552 HR, 6695 LP
PD03	24/01/2014	123208	Daily service, replaced -8 hose, check cable reel f	Preventative Maintenance		1552 HR, 6695 LP
PD03	25/01/2014	123255	Adjusted up drifter slides, carried out rod alignme	Breakdown		6699 LP
PD03	25/01/2014	123240	Daily service, changed out regulator base, replace	Preventative Maintenance		6699 LP
PD03	26/01/2014	123291	Daily Service, adjust drifter slides high free feed.M	Preventative Maintenance		1554 HR, 6703 LP
PD03	27/01/2014	123312	Daily Service, make up new stinger.MEMS W/O 123312	Preventative Maintenance		1555 HR, 6706 LP
PD03	28/01/2014	123345	Daily Service & replaced blown hoseMEMS W/O 123345	Breakdown		1556 HR, 6709 LP
PD03	28/01/2014	123367	Daily Service, replaced blown fuse & Replace -8 h	Breakdown		1556 HR, 6709 LP
PD03	29/01/2014	123408	Replace oil filler pump.MEMS W/O 123408	Corrective Maintenance		1557 HR, 6713 LP
PD03	30/01/2014	123425	D/S, replace rod arm pin & repair clino cableMEM	Preventative Maintenance		1558 HR, 6715 LP
PD03	30/01/2014	123440	D/S,C/O -6 hose, bolt up rod handler, leaking fitti	Breakdown		1558 HR, 6715 LP
PD03	31/01/2014	123470	C/O oil filler pump,C/O impulse cyl & 4 joy stick b	Breakdown		6717 LP
PD03	31/01/2014	123489	D/S, Download data & water faultMEMS W/O 123489	Preventative Maintenance		6717 LP
PD03	1/02/2014	123498	Daily Service, cleaned up all terminals & checked	Breakdown		6724 LP
PD03	2/02/2014	123550	Daily Service & murhead low oil pressure faultME	Breakdown		6729 LP
PD03	2/02/2014	123560	Daily Service, repair no percussion, replaced blowr	Breakdown		6729 LP
PD03	3/02/2014	123576	Daily Service & replaced mud seperatorMEMS W/O 123576	Breakdown		1559 HR, 6732 LP
PD03	4/02/2014	123626	Daily Service, replaced blown hose, replaced RH &	Breakdown		6740 LP
PD03	4/02/2014	123610	Daily Service, unblock oil cooler, throttle repairs &	Breakdown		6740 LP
PD03	5/02/2014	123667	2 Weekly Service. Front RHS jackleg creeping. R	Preventative Maintenance		1560 HR, 6743 LP
PD03	5/02/2014	123646	Pack up machineMEMS W/O 123646	Corrective Maintenance		1560 HR, 6743 LP
PD03	6/02/2014	123686	Daily service, adjusted precussion pressure.MEMS	Preventative Maintenance		1564 HR, 6745 LP
PD03	7/02/2014	123754	Daily Service, X9 sensor.MEMS W/O 123754	Preventative Maintenance		1565 HR, 6749 LP
PD03	7/02/2014	123768	Repair on/off switch plus wiring to clino screen.M	Breakdown		1565 HR, 6749 LP
PD03	9/02/2014	123789	Replaced load up solenoid, replaced knockout stop	Breakdown		6758 LP
PD03	10/02/2014	123813	Drill fault, loosing percussion. Replaced 2 x blown	Breakdown		1569 HR, 6763 LP
PD03	10/02/2014	123837	Not drilling, anti jam fault rotation 90 bar.MEMS	Breakdown		1569 HR, 6763 LP
PD03	11/02/2014	123891	Daily Service & fit ball bearing to check valveMEM	Breakdown		6768 LP
PD03	11/02/2014	123874	Test rollover, feed cylinder, front and rear stinger	Corrective Maintenance		6768 LP
PD03	12/02/2014	123903	Daily Service, cleaned x 9 sensor plugMEMS W/O 123903	Breakdown		6771 LP
PD03	15/02/2014	123980	Daily Service, replaced feed rope & repaired X 9 c	Breakdown		6783 LP
PD03	15/02/2014	123999	Daily Service, replaced pito cylinder hoses x 3, ad	Breakdown		6783 LP
PD03	16/02/2014	124027	Daily Service, jump start twice & refittedd hose o	Breakdown		6793 LP
PD03	17/02/2014	124060	Daily Service, replaced -6 blown hose, replaced w	Preventative Maintenance		
PD03	18/02/2014	124103	End of rail u/s.MEMS W/O 124103	Breakdown		1572 HR
PD03	19/02/2014	124146	2 Weekly ServiceMEMS W/O 124146	Preventative Maintenance		6806 LP
PD03	19/02/2014	124160	Finish ServiceMEMS W/O 124160	Breakdown		6806 LP
PD03	20/02/2014	124181	Changed -8 hose, adjusted drifter slides, tightene	Breakdown		1574 HR, 6807 LP
PD03	20/02/2014	124213	Daily service, checked rod handler.MEMS W/O 124213	Preventative Maintenance		1574 HR, 6807 LP
PD03	21/02/2014	124237	Bottom set of grippers getting damaged when coi	Breakdown		1575 HR
PD03	21/02/2014	124256	Daily service , tightened up all rod handler adjust	Preventative Maintenance		1575 HR
PD03	22/02/2014	124288	Daily Service, adjust slides for free feed.MEMS W/O 124288	Preventative Maintenance		1577 HR, 6814 LP
PD03	23/02/2014	124304	C/O rod handler switch, adjust rod handlers hittin	Breakdown		1578 HR, 6817 LP
PD03	23/02/2014	124303	Daily Service, measure spigot length.MEMS W/O 124303	Preventative Maintenance		1578 HR, 6817 LP
PD03	24/02/2014	124337	Daily Service & adjusted threading speed (Maxed	Breakdown		6826 LP

PD03	25/02/2014	124375	Daily Service, fit air hose & engine oil pressure switch	Breakdown	6833 LP
PD03	26/02/2014	124404	D/S & adj reaming mode rot & feed pressures	Preventative Maintenance	1579 HR
PD03	27/02/2014	124441	D/S and feed fault holding pressure	Breakdown	1582 HR, 6836 LP
PD03	27/02/2014	124431	Daily service & check lube delivery	Preventative Maintenance	1582 HR, 6836 LP
PD03	28/02/2014	124456	D/S & check for feed fault	Preventative Maintenance	6846 LP
PD03	1/03/2014	124480	D/S check water pump seized??	Breakdown	
PD03	1/03/2014	124544	Fit new water pump, modify to fit	Breakdown	
PD03	2/03/2014	124496	Daily Service & replaced blown hose	Breakdown	1583 HR, 6854 LP
PD03	2/03/2014	124505	Repair feed cylinder fittings & feed fault	Breakdown	1583 HR, 6854 LP
PD03	3/03/2014	124574	Remove stripped pitto cylinder and repair.	Breakdown	1585 HR, 6857 LP
PD03	3/03/2014	124559	Replace pitto jaws bolts, X 10 clino cable, 2 x hoses	Breakdown	1585 HR, 6857 LP
PD03	4/03/2014	124605	Daily Service, Replaced check valve on lift cylinder	Breakdown	1586 HR, 6869 LP
PD03	4/03/2014	124619	Daily Service, replaced pitto cylinder	Breakdown	1586 HR, 6869 LP
PD03	5/03/2014	124625	2 Weekly Service. Roll over & boom tired ?.	Preventative Maintenance	1587 HR, 6873 LP
PD03	5/03/2014	124626	Finish service & Machine broken down going to work	Breakdown	1587 HR, 6873 LP
PD03	6/03/2014	124671	Changed out feed adjuster, minor adjustments to	Breakdown	1588 HR, 6874 LP
PD03	6/03/2014	124697	Daily service, take R.D.S.A. download with laptop	Preventative Maintenance	1588 HR, 6874 LP
PD03	7/03/2014	124728	Daily service, changed -6 hose .	Preventative Maintenance	1590 HR, 6876 LP
PD03	7/03/2014	124713	Daily service, changed out blown hose.	Preventative Maintenance	1590 HR, 6876 LP
PD03	7/03/2014	124729	Zoom assembly coming apart, removed broken bolts	Breakdown	1590 HR, 6876 LP
PD03	8/03/2014	124741	Brock zoom cylinder bolts Zoom flogged out	Breakdown	1592 HR, 6879 LP
PD03	8/03/2014	124748	Finish assembling zoom tube	Breakdown	1592 HR, 6879 LP
PD03	9/03/2014	124781	Daily Service, pump squeeling, repair pito jaws.	Preventative Maintenance	
PD03	10/03/2014	124812	C/O blown hose, c/o suction hose and return filter	Breakdown	1593 HR
PD03	10/03/2014	124829	Pump noise	Corrective Maintenance	1593 HR
PD03	11/03/2014	124849	Fault find hyd fault	Breakdown	6885 LP
PD03	11/03/2014	124838	Try sorting out Drifter fault, replaced RH accumulator	Breakdown	6885 LP
PD03	13/03/2014	124930	Daily service tighten rod arm bolts	Preventative Maintenance	1595 HR, 6888 LP
PD03	14/03/2014	124968	D/S & adj rod handler & check oil filler pump	Preventative Maintenance	6896 LP
PD03	14/03/2014	124948	D/S & C/O damaged clino cable	Breakdown	6896 LP
PD03	15/03/2014	124982	Replaced both accumulators & reseal shuttle cap	Breakdown	
PD03	16/03/2014	125024	Daily Service Try to reseal LP accumulator Try repair	Breakdown	
PD03	16/03/2014	125010	Daily Service, replaced lube regulator & drill out block	Breakdown	
PD03	17/03/2014	125078	-6 hose, re seal compensator valve, replace pilot	Breakdown	1597 HR, 6907 LP
PD03	17/03/2014	125058	Daily Service, inspect boom creeping and drifter creep	Preventative Maintenance	1597 HR, 6907 LP
PD03	18/03/2014	125099	RDSA out to inspect Drifter	Corrective Maintenance	1598 HR, 6910 LP
PD03	19/03/2014	125130	6 Monthly Service. Front Pito mount plate has a crack	Preventative Maintenance	1599 HR, 6915 LP
PD03	19/03/2014	125129	Run up drifter check all pressures	Breakdown	1599 HR, 6915 LP
PD03	20/03/2014	125198	Replaced H/P oil filter.	Breakdown	1600 HR, 6919 LP
PD03	21/03/2014	125217	Adjusted dampening pressure , checked accumulator	Preventative Maintenance	1601 HR, 6920 LP
PD03	22/03/2014	125244	Daily service, remount pito jaws and adjust rod handler	Preventative Maintenance	1602 HR
PD03	22/03/2014	125232	Daily service, tightened up loose fittings.	Preventative Maintenance	1602 HR
PD03	23/03/2014	125295	Blown hose, adjust front rod handler arm.	Breakdown	
PD03	24/03/2014	125332	Daily Service & replaced bolt in Pito jaws	Breakdown	1603 HR, 6930 LP
PD03	25/03/2014	125381	Daily Service, blown hose.	Preventative Maintenance	1604 HR, 6931 LP
PD03	25/03/2014	125366	Daily Service, replace missing bolts, adjust rod arm	Preventative Maintenance	1604 HR, 6931 LP
PD03	26/03/2014	125402	C/O water flushing seals and fit water strainer.	Corrective Maintenance	6934 LP
PD03	28/03/2014	125468	Daily service replace stinger pin	Preventative Maintenance	6942 LP
PD03	29/03/2014	125511	Daily Service, inspect drifter shuttle, may be jammed	Preventative Maintenance	6945 LP
PD03	29/03/2014	125490	Daily Service, replaced blown hose & percussion block	Breakdown	6945 LP
PD03	30/03/2014	125540	Daily Service, clean air charge valve, strip & clean	Breakdown	1605 HR, 6953 LP
PD03	30/03/2014	125525	Daily Service, repaired oil leak on drifter & replaced	Breakdown	1605 HR, 6953 LP
PD03	31/03/2014	125562	Remove & free up seized water mist directional valve	Breakdown	1606 HR, 6954 LP
PD03	2/04/2014	125629	Daily Service & replaced shank	Preventative Maintenance	6962 LP
PD03	3/04/2014	125684	Finish off couple things from service, get air mist	Corrective Maintenance	1607 HR, 6968 LP
PD03	3/04/2014	125669	Pump plodded noisey again. 2 Weekly Service.	Corrective Maintenance	1607 HR, 6968 LP
PD03	5/04/2014	125727	Daily Service, park brake fault	Preventative Maintenance	
PD03	6/04/2014	125771	Daily Service & inspect pos 2 jack creeping ?	Breakdown	1611 HR, 6970 LP
PD03	7/04/2014	125795	Daily Service, replace check valve on jackleg.	Preventative Maintenance	1612 HR, 6975 LP
PD03	8/04/2014	125815	Daily Service & adjust rod handlers	Breakdown	1613 HR, 6977 LP
PD03	9/04/2014	125866	Daily Service & adjust rotation pressure	Preventative Maintenance	6983 LP
PD03	10/04/2014	125898	Daily service,adj rod arms	Preventative Maintenance	1614 HR, 6985 LP
PD03	10/04/2014	125887	Daily service,hyd over temp extend vent,replace filter	Preventative Maintenance	1614 HR, 6985 LP
PD03	11/04/2014	125909	Adj rod grippers ,repair oil leaks	Breakdown	1616 HR, 6989 LP
PD03	11/04/2014	125930	AFFF fault broken wire in centre hitch,adj slides,check	Breakdown	1616 HR, 6989 LP
PD03	11/04/2014	125920	Daily service,hyd hose,tram noise,air mist fault & check	Preventative Maintenance	1616 HR, 6989 LP
PD03	12/04/2014	125954	Daily Service & p/brake fault, cable limit switch	Preventative Maintenance	1617 HR, 6991 LP
PD03	12/04/2014	125961	Daily Service & replaced blown hose	Preventative Maintenance	1617 HR, 6991 LP
PD03	13/04/2014	125977	Daily Service & replaced blown hose	Breakdown	1618 HR, 6996 LP
PD03	14/04/2014	126030	Daily Service & replaced slides	Breakdown	6998 LP
PD03	14/04/2014	126009	Daily Service, replaced RH lift cylinder check valve	Breakdown	6998 LP
PD03	15/04/2014	126044	Daily Service, adjust slides, adjust lube pressure,	Breakdown	1620 HR, 7003 LP
PD03	16/04/2014	126097	2 Weekly Service. Fit pin to front stinger cyl, replace	Preventative Maintenance	7008 LP
PD03	16/04/2014	126112	Daily service, checked boom angle sensor calibration	Preventative Maintenance	7008 LP
PD03	17/04/2014	126150	No power to operator joystick due to broken wire	Breakdown	1622 HR, 7010 LP
PD03	17/04/2014	126140	Repair unthreading and threading fault.	Breakdown	1622 HR, 7010 LP

PD03	18/04/2014	126158	Daily service, run up test.MEMS W/O 126158	Preventative Maintenance	1624 HR, 7012 LP
PD03	19/04/2014	126205	X10 clino cable u/s, made up new one.MEMS W/O 126205	Breakdown	7016 LP
PD03	20/04/2014	126232	Changed out u/s clino cable, unseized hose reel, & replaced	Breakdown	1627 HR, 7017 LP
PD03	21/04/2014	126279	Blown HoseMEMS W/O 126279	Breakdown	7018 LP
PD03	22/04/2014	126295	Daily service rear stinger o ring C/OMEMS W/O 126295	Preventative Maintenance	7027 LP
PD03	26/04/2014	126435	Daily Service & replaced blown hoseMEMS W/O 126435	Breakdown	7038 LP
PD03	27/04/2014	126461	Daily Service & replaced blown hoseMEMS W/O 126461	Breakdown	1631 HR, 7047 LP
PD03	28/04/2014	126480	Daily Service & outrigger fittingMEMS W/O 126480	Breakdown	7051 LP
PD03	29/04/2014	126534	Daily Service & replaced blown hose & fittingsMEMS W/O 126534	Breakdown	1632 HR, 7053 LP
PD03	30/04/2014	126556	2 Weekly Service. Grinding noise getting worse vMEMS W/O 126556	Preventative Maintenance	1633 HR, 7054 LP
PD03	30/04/2014	126579	Replaced blown jack leg hose, get air mist workinMEMS W/O 126579	Breakdown	1638 HR, 7054 LP
PD03	1/05/2014	126590	Replaced 2 x blown hoses underneath carrier bolMEMS W/O 126590	Breakdown	1636 HR, 7055 LP
PD03	2/05/2014	126671	Daily Service & kick out fault low air pressureMEMS W/O 126671	Breakdown	1637 HR
PD03	3/05/2014	126682	Daily Service, tighten loose drifter feed cyl fittingsMEMS W/O 126682	Preventative Maintenance	7062 LP
PD03	4/05/2014	126736	Daily service, changed out bolt broken on rope laMEMS W/O 126736	Preventative Maintenance	1638 HR, 7063 LP
PD03	4/05/2014	126717	Daily service. Change out grease pump.MEMS W/O 126717	Preventative Maintenance	1638 HR, 7063 LP
PD03	5/05/2014	126750	Tighten up loose hose, check out cable reel problMEMS W/O 126750	Breakdown	7064 LP
PD03	7/05/2014	126847	Daily service & repairsMEMS W/O 126847	Preventative Maintenance	1642 HR, 7070 LP
PD03	7/05/2014	126829	Daily Service & replaced blown hoseMEMS W/O 126829	Breakdown	1642 HR, 7070 LP
PD03	8/05/2014	126877	Daily service & seat repairsMEMS W/O 126877	Preventative Maintenance	7077 LP
PD03	9/05/2014	126922	Daily service & C/O broken feed rope boltMEMS W/O 126922	Preventative Maintenance	7079 LP
PD03	9/05/2014	126902	Daily service & fit new seatMEMS W/O 126902	Preventative Maintenance	7079 LP
PD03	10/05/2014	126938	Daily Service, replace blown hose & fit rod handleMEMS W/O 126938	Breakdown	1643 HR, 7086 LP
PD03	11/05/2014	126978	Inspect problem feed rope, rope u/s.MEMS W/O 126978	Breakdown	7089 LP
PD03	11/05/2014	127003	Replaced u/s feed rope, replaced dozer plate boltMEMS W/O 127003	Breakdown	7089 LP
PD03	13/05/2014	127077	Daily service, top up compressor oil, check feed pMEMS W/O 127077	Preventative Maintenance	1645 HR, 7094 LP
PD03	14/05/2014	127098	2 Weekly ServiceMEMS W/O 127098	Preventative Maintenance	1646 HR, 7097 LP
PD03	14/05/2014	127113	Replaced -8 hose.MEMS W/O 127113	Breakdown	1646 HR, 7097 LP
PD03	15/05/2014	127137	Daily service, replaced grease gun, adjusted feedMEMS W/O 127137	Preventative Maintenance	1648 HR, 7101 LP
PD03	16/05/2014	127177	Daily service, reseal flushing head.MEMS W/O 127177	Corrective Maintenance	1649 HR, 7103 LP
PD03	17/05/2014	127224A	Daily service, repaired hyd leak on boom.MEMS W/O 127224A	Preventative Maintenance	1651 HR, 7106 LP
PD03	19/05/2014	127290A	Daily service check for hyd oil in drifterMEMS W/O 127290A	Preventative Maintenance	7124 LP
PD03	20/05/2014	127321	Daily Service & inspect oil leak on DrifterMEMS W/O 127321	Breakdown	1653 HR, 7132 LP
PD03	20/05/2014	127344	Daily Service, fault find oil leak & 2 x blown hosesMEMS W/O 127344	Breakdown	1653 HR, 7132 LP
PD03	21/05/2014	127383	Broken strapping bolt.MEMS W/O 127383	Breakdown	1654 HR, 7137 LP
PD03	21/05/2014	127377	Daily Service, co mex head seals leaking.MEMS W/O 127377	Preventative Maintenance	1654 HR, 7137 LP
PD03	22/05/2014	127398	Daily service & C/O failed drifter, Drifter off AVO0MEMS W/O 127398	Breakdown	7144 LP
PD03	23/05/2014	127433	Daily service & C/O shank and broken fittingsMEMS W/O 127433	Preventative Maintenance	1655 HR, 7145 LP
PD03	24/05/2014	127459	C/O blown HP accumulatorMEMS W/O 127459	Breakdown	1657 HR, 7146 LP
PD03	24/05/2014	127473	Daily Service, change X10 Cable.MEMS W/O 127473	Preventative Maintenance	1657 HR, 7146 LP
PD03	25/05/2014	127515	Daily Service, adjusted rotation & feed speeds, byMEMS W/O 127515	Breakdown	1659 HR, 7150 LP
PD03	25/05/2014	127503	Daily Service, replaced feed rope bolt, reset anti jMEMS W/O 127503	Breakdown	1659 HR, 7150 LP
PD03	26/05/2014	127543	Daily Service & swop anti jam hoses aroundMEMS W/O 127543	Breakdown	7154 LP
PD03	28/05/2014	127609	2 Weekly Service. Water tap stiff, replaced DrifteMEMS W/O 127609	Preventative Maintenance	7164 LP
PD03	28/05/2014	127581	Finish serviceMEMS W/O 127581	Breakdown	7164 LP
PD03	29/05/2014	127645	Daily service, replaced doudy seal on feed cylindMEMS W/O 127645	Preventative Maintenance	1661 HR, 7168 LP
PD03	30/05/2014	127683	Daily service, build up / weld in spacers at bottonMEMS W/O 127683	Preventative Maintenance	1662 HR, 7173 LP
PD03	1/06/2014	127751	Bypass test drifter feed cylinder, download data.MEMS W/O 127751	Breakdown	1664 HR, 7181 LP
PD03	1/06/2014	127774	No feed due to rig going into anti jam, adjusted FMEMS W/O 127774	Breakdown	1664 HR, 7181 LP
PD03	2/06/2014	127796	Blown hoseMEMS W/O 127796	Breakdown	7187 LP
PD03	2/06/2014	127790A	Daily Service & check rail fault (Dry rail)MEMS W/O 127790A	Breakdown	7187 LP
PD03	3/06/2014	127833	Daily Service, top up compressor oil & replaced rodMEMS W/O 127833	Breakdown	7195 LP
PD03	4/06/2014	127869	Daily Service, jump started 3 x sparky to check trMEMS W/O 127869	Breakdown	7199 LP
PD03	5/06/2014	127901	Daily service & drifter slidesMEMS W/O 127901	Preventative Maintenance	1665 HR, 7204 LP
PD03	6/06/2014	127946	Daily service,C/O high pressure acc. Check anti jamMEMS W/O 127946	Preventative Maintenance	1666 HR, 7207 LP
PD03	6/06/2014	127962	Daily service,drifter leaks & rod handler repairsMEMS W/O 127962	Preventative Maintenance	1666 HR, 7207 LP
PD03	8/06/2014	128012	Daily Service & replaced blown hoseMEMS W/O 128012	Breakdown	1668 HR, 7214 LP
PD03	8/06/2014	128035	Daily Service & threading speed adjustmentMEMS W/O 128035	Breakdown	1668 HR, 7214 LP
PD03	9/06/2014	128046	Daily Service, replaced drifter feed cylinder, adjustMEMS W/O 128046	Breakdown	7219 LP
PD03	11/06/2014	128140	3 Monthly Service. Engine mounts ordered surfacMEMS W/O 128140	Preventative Maintenance	
PD03	11/06/2014	128131	Finish service & park brake faultMEMS W/O 128131	Breakdown	
PD03	12/06/2014	128187	Daily Service, down load data, Cleaned out doublMEMS W/O 128187	Breakdown	1673 HR, 7225 LP
PD03	12/06/2014	128162	Daily Service, modify rod handlers support rod &MEMS W/O 128162	Breakdown	1673 HR, 7225 LP
PD03	14/06/2014	128247	Daily Service, attempt to line up rods, replaced HMEMS W/O 128247	Breakdown	7233 LP
PD03	14/06/2014	128233	Rod handlers creeping, slow feed Adjust slidesMEMS W/O 128233	Breakdown	7233 LP
PD03	15/06/2014	128283	Fit new rail end plate, adjust rod handlers, adjustMEMS W/O 128283	Breakdown	7237 LP
PD03	15/06/2014	128265	Rod handler creeps, repair and adjust speeds onMEMS W/O 128265	Breakdown	7237 LP
PD03	16/06/2014	128291	Daily Service & replaced blown hoseMEMS W/O 128291	Breakdown	7241 LP
PD03	17/06/2014	128346	Daily Service & filled compressorMEMS W/O 128346	Preventative Maintenance	7250 LP
PD03	17/06/2014	128336	Daily Service , X 9 fault, replaced cable & replaceMEMS W/O 128336	Breakdown	7250 LP
PD03	18/06/2014	128383A	Clino fault & blown hoseMEMS W/O 128383	Breakdown	7255 LP
PD03	18/06/2014	128375	Remove resolver unit, clean all plugs, calibrate X1MEMS W/O 128375	Breakdown	7255 LP
PD03	19/06/2014	128403	Replace mushroom bolt,-8 hose,grind pito jaws &MEMS W/O 128403	Breakdown	7260 LP
PD03	20/06/2014	128448	Start Fault.MEMS W/O 128448	Breakdown	1676 HR, 7265 LP
PD03	21/06/2014	128492	C/O us gripper pito cylinder.MEMS W/O 128492	Breakdown	7270 LP
PD03	21/06/2014	128468	Daily Service, replace profile bolts, adjust rod harMEMS W/O 128468	Preventative Maintenance	7270 LP

PD03	22/06/2014	128514	Daily Service & replaced blown hosesMEMS W/O	Breakdown	1678 HR
PD03	23/06/2014	128552	C/O us fitting, set free feed, turn drifter slides arc	Breakdown	1679 HR, 7273 LP
PD03	24/06/2014	128574	Blown hose, change shank, drifter broken strapping	Breakdown	1682 HR, 7280 LP
PD03	24/06/2014	128581	C/O Drifter. Broken strapping bolt u/s. Mems Wor	Breakdown	1682 HR, 7280 LP
PD03	25/06/2014	128614	Finish service, change dump cylinderMEMS W/O	Breakdown	1683 HR
PD03	26/06/2014	128588	2 Weekly Service. Stingers side ways play needs	Preventative Maintenance	1689 HR, 7285 LP
PD03	26/06/2014	128686	C/O broken shank drifter, rod handler alignment &	Breakdown	1689 HR, 7285 LP
PD03	26/06/2014	128697	C/O Broken shank, rod handler alignment.MEMS W	Breakdown	1689 HR, 7285 LP
PD03	26/06/2014	128689	Daily Service, adjusted threading speed, adjusted	Breakdown	1689 HR, 7285 LP
PD03	27/06/2014	128666	Adjust Drifter and rod handlers, c/o us control val	Breakdown	1690 HR, 7288 LP
PD03	27/06/2014	128711	C/O feed cylionder, check alignment.MEMS W/O	Breakdown	1690 HR, 7288 LP
PD03	28/06/2014	128641	Daily Service, reset stand by pressure adjusted fu	Breakdown	1691 HR, 7291 LP
PD03	29/06/2014	128752	Daily Service, return filter light, 1 x fitting, c/o sh	Preventative Maintenance	7295 LP
PD03	30/06/2014	128781	Daily Service, shimmed up pito cylindersremoved	Breakdown	1692 HR, 7304 LP
PD03	2/07/2014	128850	D/S drill fault reset RPCF valve C/O ramp up coil	Breakdown	7321 LP
PD03	2/07/2014	128837	Daily service & C/O din plug on ramp up coilMEM	Breakdown	7321 LP
PD03	3/07/2014	128875	Daily service & replace drifter boltMEMS W/O 128	Preventative Maintenance	1694 HR, 7325 LP
PD03	4/07/2014	128922	Daily service & 2 hyd hosesMEMS W/O 128922	Preventative Maintenance	1696 HR, 7328 LP
PD03	4/07/2014	128917	Daily service & weld repairsMEMS W/O 128917	Preventative Maintenance	1696 HR, 7328 LP
PD03	5/07/2014	128938	Weld repair to rod handler stopper adj and refit	Breakdown	7334 LP
PD03	6/07/2014	128980	Daily Service & drill adjustment ?MEMS W/O 1289	Breakdown	1697 HR, 7337 LP
PD03	7/07/2014	128993	Daily Service, slow down rotaion speed reset RPC	Breakdown	7341 LP
PD03	8/07/2014	129066	Daily Service, set RCPF valve.MEMS W/O 129066	Preventative Maintenance	1698 HR, 7350 LP
PD03	9/07/2014	129075	2 Weekly Service, RDSA carry out lube audit.MEM	Preventative Maintenance	1699 HR, 7352 LP
PD03	9/07/2014	129102	Fit zoom tube clino cable, clean X9, Rod Handler,	Breakdown	1699 HR, 7352 LP
PD03	14/07/2014	129208	Daily service & HP accumulator and lazer faultM	Preventative Maintenance	
PD03	15/07/2014	129235	Clean lazer circuit board& C/O park brake latchin	Breakdown	1706 HR, 7365 LP
PD03	15/07/2014	129252	Daily service jump start & test charge circuitMEM	Breakdown	1706 HR, 7365 LP
PD03	16/07/2014	129274	Daily service & new trailing cableMEMS W/O 1292	Breakdown	1707 HR, 7370 LP
PD03	18/07/2014	129360	Daily service & adj carousel drumMEMS W/O 129	Preventative Maintenance	1711 HR, 7378 LP
PD03	19/07/2014	129389	Blown Hose, top up compressor, pitto jaw bolts.M	Breakdown	1712 HR, 7383 LP
PD03	19/07/2014	129410	Hose, fittings, re gas drifter, remove pitto jaws w	Breakdown	1712 HR, 7383 LP
PD03	20/07/2014	129422	Daily Service, fit pitto jaws.MEMS W/O 129422	Preventative Maintenance	7387 LP
PD03	20/07/2014	129444	Drilling percussion fault, 2 x shanks, c/o high / lo	Breakdown	7387 LP
PD03	21/07/2014	129457	Change out feed cylinder, set up dampning press	Breakdown	1713 HR, 7393 LP
PD03	21/07/2014	129505	Hyd oil leak.MEMS W/O 129505	Breakdown	1713 HR, 7393 LP
PD03	22/07/2014	129513	Daily Service & replaced blown hoseMEMS W/O 1	Breakdown	1714 HR, 7397 LP
PD03	22/07/2014	129480	Not startingMEMS W/O 129480	Preventative Maintenance	1714 HR, 7397 LP
PD03	22/07/2014	129477	Park Brake applying.MEMS W/O 129477	Breakdown	1714 HR, 7397 LP
PD03	23/07/2014	129527	2 Weekly Service, boyse repair park brake applyir	Preventative Maintenance	1717 HR, 7399 LP
PD03	23/07/2014	129559	RepairsMEMS W/O 129559	Breakdown	1717 HR, 7399 LP
PD03	24/07/2014	129566	Daily Service & collaring faultMEMS W/O 129566	Breakdown	1719 HR, 7403 LP
PD03	24/07/2014	129601	Fit wiring on zoom sensor & Daily ServiceMEMS W	Breakdown	1719 HR, 7403 LP
PD03	25/07/2014	129639	Daily Service & repaired fuel gaugeMEMS W/O 12	Breakdown	1720 HR, 7410 LP
PD03	26/07/2014	129611	Daily Service, tightened fitting & added fuelMEMS	Breakdown	1721 HR, 7411 LP
PD03	27/07/2014	129666	Daily Service, hose pitos up, replaced Drifter shoe	Breakdown	7417 LP
PD03	28/07/2014	129699	Daily Service, replaced blow hose, slow down rota	Breakdown	7420 LP
PD03	28/07/2014	129704	Daily Service, replaced return ropeMEMS W/O 12	Breakdown	7420 LP
PD03	29/07/2014	129720	Daily Service & replaced blown hose & strapping	Breakdown	1722 HR, 7424 LP
PD03	30/07/2014	129764	Blown Hose, feed rope bolt.MEMS W/O 129764	Breakdown	7426 LP
PD03	31/07/2014	129796	C/O drifter , cradle ,rod changer alignment & gas	Breakdown	7433 LP
PD03	31/07/2014	129787	Daily service ,top up compressor oil & broken stra	Breakdown	7433 LP
PD03	1/08/2014	129831	Daily service & adj rod changersMEMS W/O 1298	Preventative Maintenance	1724 HR, 7438 LP
PD03	1/08/2014	129822	Daily service check pressures drilling goodMEMS	Preventative Maintenance	1724 HR, 7438 LP
PD03	2/08/2014	129844	Daily Service, adjust all drill pressures & RPCFME	Breakdown	7444 LP
PD03	3/08/2014	129889	Daily Service & replaced drifter feed cylinderMEM	Breakdown	1726 HR, 7450 LP
PD03	5/08/2014	129934	Daily Service & air flush fault (Tap of)MEMS W/O	Breakdown	1732 HR, 7454 LP
PD03	6/08/2014	129972	Daily Service, repair wiring behind isolator, tighte	Breakdown	7458 LP
PD03	7/08/2014	130002	2 Weekly Service, replaced feed cylinder.MEMS W	Preventative Maintenance	1733 HR, 7461 LP
PD03	7/08/2014	130054	Finish off service.MEMS W/O 130054	Corrective Maintenance	1733 HR, 7461 LP
PD03	7/08/2014	130055	Replaced clino cable.MEMS W/O 130055	Breakdown	1733 HR, 7461 LP
PD03	8/08/2014	130075	Adjusted rod alignment, checked accumulators, b	Corrective Maintenance	1736 HR, 7465 LP
PD03	8/08/2014	130066	Replaced 3 x -6 hoses , 2x fittings, regased accur	Breakdown	1736 HR, 7465 LP
PD03	9/08/2014	130097	Daily Service, re gas accumulators, -16 fitting.ME	Breakdown	1739 HR, 7469 LP
PD03	9/08/2014	130091	Machine vibrating, hoses vibrating, bypass percus	Corrective Maintenance	1739 HR, 7469 LP
PD03	10/08/2014	130165	Drifter Change, vibrating hoses and rig. Hoses vit	Breakdown	7475 LP
PD03	10/08/2014	130144	Replaced Drifter hoses, run up & test pressures, r	Breakdown	7475 LP
PD03	11/08/2014	130193	Change feed cylinder, tighten pitto bolts, threadir	Breakdown	1740 HR, 7477 LP
PD03	11/08/2014	130183	Replaced LH joystick & repaired wiring to joystick	Breakdown	1740 HR, 7477 LP
PD03	12/08/2014	130213	No joystick functions, repair 2 x breaks in wires u	Breakdown	7481 LP
PD03	13/08/2014	130269	Adjust pitto cylinder, adjust drifter, rod handlers,	Breakdown	1741 HR, 7485 LP
PD03	13/08/2014	130245	U/S Pitto jaw housing, re heli coil.MEMS W/O 130	Breakdown	1741 HR, 7485 LP
PD03	15/08/2014	130316	Daily service C/O blown hyd hoseMEMS W/O 130	Preventative Maintenance	7492 LP
PD03	16/08/2014	130345	Daily Service & unblocked air lineMEMS W/O 130	Breakdown	1743 HR, 7502 LP
PD03	16/08/2014	130363	Daily Service & water leak under carrierMEMS W/	Breakdown	1743 HR, 7502 LP
PD03	17/08/2014	130395	Clino repairs.MEMS W/O 130395	Breakdown	7506 LP

PD03	19/08/2014	130465	2 Weekly Service. Floor mounts u/s. Water Leak	Preventative Maintenance	1745 HR, 7511 LP
PD03	19/08/2014	130448	Daily Service & clino repairs	MEMS W/O 130448 Breakdown	1745 HR, 7511 LP
PD03	19/08/2014	130459	Daily Service, c/o fire extinguisher & inspect clino	Preventative Maintenance	1745 HR, 7511 LP
PD03	20/08/2014	130485	Finish electrical repairs and weld new threaded pi	Corrective Maintenance	1747 HR, 7514 LP
PD03	21/08/2014	130498	Asist drill fitter, c/o rotation motor, carry out othe	Corrective Maintenance	1748 HR, 7514 LP
PD03	21/08/2014	130522	Daily service, changed h/p accumulator, regassed	Preventative Maintenance	1748 HR, 7514 LP
PD03	21/08/2014	130499	Replaced clino cable x 10 , replaced -6 hose.	MEMS Breakdown	1748 HR, 7514 LP
PD03	22/08/2014	130554	Daily Service & replaced blown hose	MEMS W/O 1 Breakdown	1748 HR, 7519 LP
PD03	22/08/2014	130569	Fitted hydraulic cooler,	MEMS W/O 130569 Breakdown	1748 HR, 7519 LP
PD03	23/08/2014	130534	Daily Service, c/o us pos 2 tyre - rim split.	MEMS \ Breakdown	1748 HR, 7526 LP
PD03	23/08/2014	130544	Daily Service, check over cooler.	MEMS W/O 1305 Preventative Maintenance	1748 HR, 7526 LP
PD03	24/08/2014	130612	K7 relay for threading u/s, blown hose.	MEMS W/(Breakdown	1749 HR, 7529 LP
PD03	24/08/2014	130592	Threading Fault, K7 relay.	MEMS W/O 130592 Breakdown	1749 HR, 7529 LP
PD03	25/08/2014	130653	x10 clino cable, tidy up and re hang hoses broke	Breakdown	1749 HR, 7532 LP
PD03	26/08/2014	130681	Fit lube level sensor, fit din plugs to threading blo	Breakdown	1750 HR, 7534 LP
PD03	27/08/2014	130716	Blown Hose.	MEMS W/O 130716 Breakdown	1751 HR, 7541 LP
PD03	28/08/2014	130729	Daily service start fault ops turning key too far	ME Preventative Maintenance	1752 HR, 7544 LP
PD03	1/09/2014	130842	Daily Service & repairs	MEMS W/O 130842 Breakdown	1759 HR, 7555 LP
PD03	1/09/2014	130851	Daily Service, regased accumulator & replaced sh	Breakdown	1759 HR, 7555 LP
PD03	3/09/2014	130890	2 Weekly Service. Fit new vibration matts to floo	Preventative Maintenance	1759 HR, 7560 LP
PD03	3/09/2014	130908	Finish service, replaced clino cable, repaired drill i	Breakdown	1759 HR, 7560 LP
PD03	4/09/2014	130928	Checked and repair threading fault, 2 way radio a	Breakdown	1760 HR, 7569 LP
PD03	4/09/2014	130956	Fitted new feed rope, repaired wiring loom for aff	Breakdown	1760 HR, 7569 LP
PD03	5/09/2014	130978	Replaced blown hose under floor	MEMS W/O 1309 Breakdown	1762 HR, 7573 LP
PD03	5/09/2014	130970	replaced hose, replaced rod arm jaw	MEMS W/O 1 Breakdown	1762 HR, 7573 LP
PD03	6/09/2014	131011	Blown Hose	MEMS W/O 131011 Breakdown	1763 HR, 7577 LP
PD03	6/09/2014	130995	Daily Service, hose.	MEMS W/O 130995 Preventative Maintenance	1763 HR, 7577 LP
PD03	7/09/2014	131032	Daily Service, no percussion kickout, loose auto r	Preventative Maintenance	1765 HR, 7586 LP
PD03	10/09/2014	131135	Daily service ,&2 hoses, clino angle measured	MEM Preventative Maintenance	1768 HR, 7599 LP
PD03	11/09/2014	131184	Daily service & drifter plug C/O	MEMS W/O 13118 Preventative Maintenance	1770 HR, 7605 LP
PD03	13/09/2014	131252	Daily service & pito fittings	MEMS W/O 131252 Preventative Maintenance	1770 HR, 7616 LP
PD03	13/09/2014	131239	Daily service & weld up hose tree bracket	MEMS V Preventative Maintenance	1770 HR, 7616 LP
PD03	13/09/2014	131241	Low compressor oil motor overload	MEMS W/O 13 Breakdown	1770 HR, 7616 LP
PD03	15/09/2014	131304	Daily Service & retorque wheels	MEMS W/O 13130 Preventative Maintenance	1773 HR, 7627 LP
PD03	16/09/2014	131341	Replaced blown hose	MEMS W/O 131341 Breakdown	
PD03	17/09/2014	131358	6 Monthly Service. Front stinger sloppy.. Rail ex	Preventative Maintenance	1776 HR, 7635 LP
PD03	18/09/2014	131412	Daily service, fitted new governor..	MEMS W/O 13 Preventative Maintenance	1778 HR, 7641 LP
PD03	18/09/2014	131390	Repaired electrical faults, no throttle, no ignition	c Breakdown	1778 HR, 7641 LP
PD03	19/09/2014	131456	Daily Service & cable reel fault (Locking up)	MEMS Breakdown	1780 HR, 7641 LP
PD03	19/09/2014	131426	Repair cable reel lose of power and tripping out	Breakdown	1780 HR, 7641 LP
PD03	20/09/2014	131441	Daily Service, start fault, rod handler alignment &	Breakdown	1780 HR, 7646 LP
PD03	21/09/2014	131485	Daily Service & circuit breaker fault	MEMS W/O 13 Breakdown	1782 HR, 7650 LP
PD03	21/09/2014	131495	Daily Service & sparky replaced 25 Amp circuit br	Preventative Maintenance	1782 HR, 7650 LP
PD03	22/09/2014	131516	Daily Service & blown hose	MEMS W/O 131516 Breakdown	1784 HR, 7652 LP
PD03	22/09/2014	131503	Daily Service, fitted X9 box lid, cleaned wiring, te	Breakdown	1784 HR, 7652 LP
PD03	23/09/2014	131525	Daily Service & free up air tap	MEMS W/O 131525 Preventative Maintenance	1784 HR, 7654 LP
PD03	24/09/2014	131551	C/O top clip on, free up zoom sensor brg, repair c	Breakdown	1784 HR, 7660 LP
PD03	24/09/2014	131565	Can comm fault repair cable	MEMS W/O 131565 Preventative Maintenance	1784 HR, 7660 LP
PD03	26/09/2014	131640	Daily service & blown hose	MEMS W/O 131640 Preventative Maintenance	1787 HR, 7668 LP
PD03	26/09/2014	131631	Daily service & C/O broken feed rope	MEMS W/O Preventative Maintenance	1787 HR, 7668 LP
PD03	27/09/2014	131666	Daily service & repair spot light	MEMS W/O 13166 Preventative Maintenance	1788 HR, 7671 LP
PD03	28/09/2014	131675	Daily Service & replaced hose	MEMS W/O 131675 Breakdown	1789 HR, 7678 LP
PD03	28/09/2014	131692	Pump not ramping up, replaced coil, replace blow	Breakdown	1789 HR, 7678 LP
PD03	29/09/2014	131707	Daily Service & replaced blown hose	MEMS W/O 1 Preventative Maintenance	1789 HR, 7679 LP
PD03	29/09/2014	131724	Daily Service & replaced blown hose	MEMS W/O 1 Preventative Maintenance	1789 HR, 7679 LP
PD03	30/09/2014	131735	Daily service, adjust pressures.	MEMS W/O 13173 Preventative Maintenance	1791 HR, 7685 LP
PD03	30/09/2014	131752	Lazer fault convertor on order Daily Service	MEMS Breakdown	1791 HR, 7685 LP
PD03	1/10/2014	131774	2 Weekly Service. Replace compressor. Hydraul	Preventative Maintenance	1792 HR, 7687 LP
PD03	1/10/2014	131781	Finished of service, problems with laser, pito cylir	Corrective Maintenance	1792 HR, 7687 LP
PD03	2/10/2014	131809	Asist and sort out lazer fault.	MEMS W/O 131809 Breakdown	1793 HR, 7690 LP
PD03	3/10/2014	131850	Daily service and repairs.	MEMS W/O 131850 Preventative Maintenance	1794 HR, 7690 LP
PD03	3/10/2014	131831	Daily service, -8 hose.	MEMS W/O 131831 Preventative Maintenance	1794 HR, 7690 LP
PD03	3/10/2014	131832	Resealed mex head , laser fault found laser and c	Breakdown	1794 HR, 7690 LP
PD03	4/10/2014	131876	Daily service and repairs.	MEMS W/O 131876 Preventative Maintenance	1795 HR, 7691 LP
PD03	4/10/2014	131867	fit new covertor, 2nd laser u/s.	MEMS W/O 13186 Breakdown	1795 HR, 7691 LP
PD03	5/10/2014	131888	Run solinoid fault, repaired wiring.	MEMS W/O 13 Breakdown	1795 HR, 7694 LP
PD03	6/10/2014	131928	Blown Hose	MEMS W/O 131928 Breakdown	1798 HR, 7700 LP
PD03	6/10/2014	131931	Fit new lasers and connect.	MEMS W/O 131931 Corrective Maintenance	1798 HR, 7700 LP
PD03	7/10/2014	131946	Daily service ,add fuel, C/O blown hyd hose	MEMS Breakdown	
PD03	8/10/2014	131994	Daily service and over ride park brake cable limit	Preventative Maintenance	
PD03	10/10/2014	132080	Daily service .repair clino bracket, recalibrate clino	Breakdown	
PD03	10/10/2014	132063	Daily service, C/O water valve, remove cable reel	Breakdown	
PD03	11/10/2014	132093	Daily service, recalibrate sensors, C/O coefficients	Breakdown	
PD03	12/10/2014	132141	Daily Service laser wiring repairs	MEMS W/O 1321 Preventative Maintenance	
PD03	13/10/2014	132167	Adjust rod handler, LH accum, test all press adjus	Corrective Maintenance	
PD03	13/10/2014	132152	Daily Service pre start issues.	MEMS W/O 132152 Preventative Maintenance	

PD03	13/10/2014	132166	NiMEMS W/O 132166	Preventative Maintenance		
PD03	14/10/2014	132188	Check clino, 90 - 90 and dump value.MEMS W/O	Corrective Maintenance		
PD03	15/10/2014	132227	2 Weekly Service. C/O turning device. C/O front	Preventative Maintenance		
PD03	15/10/2014	132221	Finish service, replaced X 9 clino cable, replaced 1	Breakdown		
PD03	16/10/2014	132271	Daily service, fit drifter slide bolt.MEMS W/O 1322	Preventative Maintenance		
PD03	16/10/2014	132238	Daily service, refit cover back on over hyd valves.	Breakdown		
PD03	18/10/2014	132320	Refit drifter hoses, tidy wrap.MEMS W/O 132320	Corrective Maintenance		
PD03	18/10/2014	132340	Replace broken strapping bolt.MEMS W/O 132340	Breakdown		
PD03	19/10/2014	132345	Daily Service and 2 x hosesMEMS W/O 132345	Breakdown		
PD03	24/10/2014	132469	Daily service C/O Drifter, rod changer alignment &	Corrective Maintenance		
PD03	15/11/2014	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1834 HR, 7844 LP
PD03	13/11/2014	200025	2 Weekly Service - Atlas 1257MEMS PM TASK 374	Preventative Maintenance		1835 HR, 7847 LP
PD03	13/11/2014	200177	Fit spot light	Corrective Maintenance	Rally 2000 from Coventrys	1835 HR, 7847 LP
PD03	14/11/2014	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1835 HR, 7847 LP
PD03	15/11/2014	200237	Blown Hose	Breakdown		
PD03	15/11/2014	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	16/11/2014	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	16/11/2014	200209	Replaced Blown Hose	Breakdown		
PD03	17/11/2014	200232	Checked Clino Operation	Corrective Maintenance		1836 HR, 7875 LP
PD03	17/11/2014	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1836 HR, 7875 LP
PD03	18/11/2014	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1838 HR, 7882 LP
PD03	19/11/2014	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1840 HR, 7887 LP
PD03	20/11/2014	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1841 HR, 7889 LP
PD03	20/11/2014	200326	Replaced Mex head fitting & Replaced feed rope	Breakdown		1841 HR, 7889 LP
PD03	21/11/2014	200330	Replaced clino cable	Breakdown		1841 HR, 7889 LP
PD03	22/11/2014	200344	C/O water hose & return rope	Breakdown		1842 HR, 7899 LP
PD03	22/11/2014	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1842 HR, 7899 LP
PD03	23/11/2014	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1843 HR, 7901 LP
PD03	24/11/2014	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1844 HR, 7908 LP
PD03	24/11/2014	200372	Drilling poorly (Regased accumulator & set damp	Breakdown		1844 HR, 7908 LP
PD03	25/11/2014	200389	Pito Jaws not holding, check pressure, removed s	Breakdown		
PD03	25/11/2014	200390	Replaced blown hoses Percussion (See Note)	Breakdown	Replaced LH accumulator, Replaced 2 x percussion hoses. Replaced fe	
PD03	26/11/2014	200400	Replaced rope ladder	Breakdown		1844 HR, 7915 LP
PD03	27/11/2014	200138	2 Weekly Service - Atlas 1257MEMS PM TASK 374	Preventative Maintenance	Service done	1845 HR, 7916 LP
PD03	27/11/2014	200471	repair l/h lazer u/s wiring 2x feed fittings and rem	Breakdown	multiple repairs has been completed	1845 HR, 7916 LP
PD03	28/11/2014	200488	Block water flushing fittings and hose.	Breakdown	UNBLOCKED FLUSHING HEAD AND HOSE.	
PD03	28/11/2014	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	29/11/2014	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1848 HR, 7922 LP
PD03	1/12/2014	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1850 HR, 7930 LP
PD03	2/12/2014	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1851 HR, 7932 LP
PD03	2/12/2014	200538	Repair wiring to sensor & pito restrictor !	Breakdown		1851 HR, 7932 LP
PD03	3/12/2014	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1853 HR, 7936 LP
PD03	4/12/2014	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1853 HR, 7942 LP
PD03	4/12/2014	200627	Replaced blown gauge hose	Breakdown		1853 HR, 7942 LP
PD03	5/12/2014	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1853 HR, 7946 LP
PD03	5/12/2014	200624	Remount Pito cylinder, shim cylinderCentralized C	Breakdown		1853 HR, 7946 LP
PD03	5/12/2014	200644	Repaired oil leak	Breakdown		1853 HR, 7946 LP
PD03	5/12/2014	200638	Replaced clino cable X 10Replaced blown hose	Breakdown		1853 HR, 7946 LP
PD03	6/12/2014	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1853 HR, 7951 LP
PD03	7/12/2014	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1854 HR, 7954 LP
PD03	8/12/2014	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1855 HR, 7958 LP
PD03	9/12/2014	200678	Adjusted rod handlers & drifter slides !	Breakdown		1857 HR, 7962 LP
PD03	9/12/2014	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1857 HR, 7962 LP
PD03	9/12/2014	200686	Replaced feed cylinder Buffer	Breakdown		1857 HR, 7962 LP
PD03	9/12/2014	200667	Replaced Flushing seals	Breakdown		1857 HR, 7962 LP
PD03	10/12/2014	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1858 HR, 7964 LP
PD03	11/12/2014	200441	3 Monthly Service - ATLAS 1257MEMS PM TASK 4	Preventative Maintenance	Made up feed cylinder spacer 5" on cylinder end	1859 HR, 7972 LP
PD03	11/12/2014	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1859 HR, 7972 LP
PD03	12/12/2014	200818	C/O X 8 clino cable	Breakdown		1863 HR, 7982 LP
PD03	12/12/2014	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1863 HR, 7982 LP
PD03	12/12/2014	200812	Fit new clino support rope	Breakdown		1863 HR, 7982 LP
PD03	12/12/2014	200770	Repaired carousel button on joystickRefitted gripp	Breakdown		1863 HR, 7982 LP
PD03	13/12/2014	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	13/12/2014	200802	Replace missing bolts	Corrective Maintenance		
PD03	13/12/2014	200805	Replace oring in flushing head	Damage		
PD03	14/12/2014	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	15/12/2014	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1865 HR, 7996 LP
PD03	15/12/2014	200823	Loose feed fittings and feed rope	Breakdown		1865 HR, 7996 LP
PD03	15/12/2014	200804	Replaced ramp up coil & harness	Breakdown		1865 HR, 7996 LP
PD03	15/12/2014	200827	us feed cylinder leaking oil	Breakdown		1865 HR, 7996 LP
PD03	16/12/2014	200847	Cylinder - Feed Thrust Changeout	Component Change out	16/12/14 6-9.30 Replaced cylinder & sent to AT	1866 HR, 7996 LP
PD03	16/12/2014	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1866 HR, 7996 LP
PD03	16/12/2014	200849	Replaced blown hose	Breakdown		1866 HR, 7996 LP
PD03	17/12/2014	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1867 HR, 7999 LP
PD03	17/12/2014	200845	Replaced blown hose	Breakdown		1867 HR, 7999 LP
PD03	18/12/2014	200878	Adjusted alignment with drifter	Breakdown		1870 HR, 8000 LP

PD03	18/12/2014	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1870 HR, 8000 LP
PD03	18/12/2014	200898	Pito Cylinder Change out	Component Change out	Cylinder to be sent to Centre engineering	1870 HR, 8000 LP
PD03	19/12/2014	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1871 HR, 8001 LP
PD03	19/12/2014	200870	Replaced blown hose	Breakdown		1871 HR, 8001 LP
PD03	20/12/2014	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	21/12/2014	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1875 HR, 8008 LP
PD03	22/12/2014	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1877 HR, 8022 LP
PD03	23/12/2014	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1879 HR, 8028 LP
PD03	24/12/2014	201026	Fitted bolts to rod guide	Breakdown		
PD03	2/01/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	3/01/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1881 HR, 8033 LP
PD03	4/01/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1881 HR, 8036 LP
PD03	5/01/2015	200739	2 Weekly Service - Atlas 1257MEMS PM TASK 374	Preventative Maintenance		
PD03	6/01/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1882 HR, 8048 LP
PD03	6/01/2015	201110	Repaired no water to drill string.	Breakdown		1882 HR, 8048 LP
PD03	7/01/2015	201122	Changed out u/s x10 clino cable, and -12 water h	Breakdown		1882 HR, 8050 LP
PD03	7/01/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1882 HR, 8050 LP
PD03	7/01/2015	201112	Replaced feed rope	Breakdown		1882 HR, 8050 LP
PD03	7/01/2015	201168	Replaced front drifter slides, adjusted rod alignme	Corrective Maintenance		1882 HR, 8050 LP
PD03	7/01/2015	201130	Weld up rod gripper arm stopper. regased accum	Breakdown		1882 HR, 8050 LP
PD03	8/01/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	8/01/2015	201160	Repaired lube oil level light.	Corrective Maintenance		
PD03	8/01/2015	201158	Repaired stripped pito jaw assembly.	Damage		
PD03	9/01/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1882 HR, 8058 LP
PD03	10/01/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1882 HR, 8065 LP
PD03	11/01/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1882 HR, 8069 LP
PD03	12/01/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1882 HR, 8074 LP
PD03	12/01/2015	201209	Repaired Exhaust on Engine	Corrective Maintenance		1882 HR, 8074 LP
PD03	12/01/2015	201204	Straighten up hose tree, replaced broken fitting.	Damage		1882 HR, 8074 LP
PD03	13/01/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1882 HR, 8081 LP
PD03	13/01/2015	201221	Replaced X 7 clino cable	Breakdown		1882 HR, 8081 LP
PD03	14/01/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1882 HR, 8086 LP
PD03	15/01/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1882 HR, 8090 LP
PD03	16/01/2015	201311	Changed out percussion hose and hour meter, to	Corrective Maintenance		1882 HR, 8094 LP
PD03	16/01/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1882 HR, 8094 LP
PD03	17/01/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1882 HR, 8094 LP
PD03	17/01/2015	201325	Replaced blown hose.	Corrective Maintenance		1882 HR, 8094 LP
PD03	17/01/2015	201312	Replaced X 9 clino sensor (Fitted old second hanc	Breakdown		1882 HR, 8094 LP
PD03	18/01/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	19/01/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	20/01/2015	201262	2 Weekly Service - Atlas 1257MEMS PM TASK 374	Preventative Maintenance		1888 HR, 8108 LP
PD03	20/01/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1888 HR, 8108 LP
PD03	20/01/2015	201213	Replace exhaust (Mammoth system)Order # 6194	Corrective Maintenance		1888 HR, 8108 LP
PD03	20/01/2015	201355	Replaced clino plug x 8 & clino sensorRecalibrate	Breakdown		1888 HR, 8108 LP
PD03	20/01/2015	201263	Test and Adjust Maximum Service Brake Pressure	Preventative Maintenance		1888 HR, 8108 LP
PD03	21/01/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1891 HR, 8108 LP
PD03	22/01/2015	201442	Adjusted Positioning pressure & checked zoom cti	Breakdown		
PD03	22/01/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	22/01/2015	201368	Fit new air Regulator.	Corrective Maintenance		
PD03	23/01/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1892 HR, 8116 LP
PD03	23/01/2015	201462	Replace broken feed rope and changed out spool	Breakdown		1892 HR, 8116 LP
PD03	24/01/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1892 HR, 8122 LP
PD03	24/01/2015	201480	Replace rod gripper arm jaw.	Breakdown	Replace rod gripper arm, re coil rollover cover, 1	1892 HR, 8122 LP
PD03	25/01/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1892 HR, 8127 LP
PD03	26/01/2015	201499	Belt brake light on, switch was bypassed , refitted	Breakdown		1893 HR, 8135 LP
PD03	26/01/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1893 HR, 8135 LP
PD03	27/01/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1893 HR, 8139 LP
PD03	28/01/2015	201521	Blown Hose	Breakdown		1893 HR, 8148 LP
PD03	28/01/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1893 HR, 8148 LP
PD03	29/01/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1893 HR, 8152 LP
PD03	30/01/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1894 HR, 8164 LP
PD03	31/01/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1894 HR, 8170 LP
PD03	1/02/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1895 HR, 8175 LP
PD03	2/02/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1897 HR
PD03	3/02/2015	201565	2 Weekly Service - Atlas 1257MEMS PM TASK 374	Preventative Maintenance		
PD03	4/02/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1898 HR, 8187 LP
PD03	5/02/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1902 HR, 8193 LP
PD03	5/02/2015	201737	Replaced blown hose	Breakdown		1902 HR, 8193 LP
PD03	6/02/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1902 HR, 8197 LP
PD03	7/02/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1903 HR, 8201 LP
PD03	7/02/2015	201746	Straighten up rear rod gripper set , drilled out bro	Corrective Maintenance		1903 HR, 8201 LP
PD03	8/02/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1904 HR, 8206 LP
PD03	8/02/2015	201761	Removed rod handlersWelded up & refitted Repla	Breakdown		1904 HR, 8206 LP
PD03	9/02/2015	201781	Adjusted carousel & straightened rod handler(Rod	Breakdown		1904 HR, 8212 LP
PD03	9/02/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1904 HR, 8212 LP
PD03	9/02/2015	201773	No power to clino screenFound wiring rubbed thri	Breakdown		1904 HR, 8212 LP

PD03	10/02/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1905 HR, 8217 LP
PD03	10/02/2015	201786	Jump Start, Test alternator, got sparky to check	Corrective Maintenance	Jump Start, Test alternator, got sparky to check	1905 HR, 8217 LP
PD03	11/02/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	11/02/2015	201794	replace -6 & -8 hyd fittings	Breakdown		
PD03	12/02/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1907 HR, 8226 LP
PD03	12/02/2015	201829	Water entered A cabinetMachine shorted out wou	Breakdown		1907 HR, 8226 LP
PD03	13/02/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1908 HR, 8233 LP
PD03	14/02/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1909 HR, 8236 LP
PD03	15/02/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1909 HR, 8238 LP
PD03	16/02/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1912 HR, 8251 LP
PD03	17/02/2015	201715	2 Weekly Service - Atlas 1257MEMS PM TASK 374	Preventative Maintenance	Replaced carousel gaurds	1912 HR, 8260 LP
PD03	18/02/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1913 HR, 8265 LP
PD03	18/02/2015	201932	Replaced blown hose & adjusted rod handlers	Breakdown		1913 HR, 8265 LP
PD03	19/02/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1914 HR, 8270 LP
PD03	20/02/2015	201952	Helicoil rear rod gripper adjuster	Breakdown		1915 HR, 8276 LP
PD03	20/02/2015	201953	Replace bottom adjuster of gripper cylinder stripp	Breakdown		1915 HR, 8276 LP
PD03	21/02/2015	201972	Blown Hydraulic Hose	Breakdown		1916 HR, 8279 LP
PD03	21/02/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1916 HR, 8279 LP
PD03	21/02/2015	201961	Replaced Hydraulic return filters.	Corrective Maintenance		1916 HR, 8279 LP
PD03	21/02/2015	201973	Return Filter Light on	Corrective Maintenance		1916 HR, 8279 LP
PD03	21/02/2015	201954	Return Filter restriction light on, c/o us terminals	Breakdown		1916 HR, 8279 LP
PD03	22/02/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1916 HR, 8284 LP
PD03	22/02/2015	201980	Pito Cylinder Change out on condition	Component Change out		1916 HR, 8284 LP
PD03	23/02/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1917 HR, 8288 LP
PD03	24/02/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1918 HR, 8293 LP
PD03	25/02/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1921 HR, 8299 LP
PD03	26/02/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1921 HR, 8301 LP
PD03	26/02/2015	202059	Helicoil & remount backing plateStraighten rod gr	Corrective Maintenance		1921 HR, 8301 LP
PD03	27/02/2015	202065	C/O PITO box	Corrective Maintenance		1921 HR, 8315 LP
PD03	27/02/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1921 HR, 8315 LP
PD03	28/02/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1921 HR, 8321 LP
PD03	1/03/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1922 HR, 8328 LP
PD03	1/03/2015	202074	Remove Rod handler & weld stopper	Corrective Maintenance		1922 HR, 8328 LP
PD03	2/03/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1922 HR, 8334 LP
PD03	3/03/2015	202023	6 Monthly Service - Atlas 1257MEMS PM TASK 42	Preventative Maintenance		1922 HR, 8334 LP
PD03	4/03/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1924 HR, 8342 LP
PD03	4/03/2015	202093	Pito Cylinder Change out on condition	Component Change out		1924 HR, 8342 LP
PD03	4/03/2015	202102	Replaced Pito jaw mounting box	Corrective Maintenance		1924 HR, 8342 LP
PD03	5/03/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1925 HR, 8346 LP
PD03	6/03/2015	202164	checked out damaged pito jaw assembly, make s	Damage		1925 HR, 8353 LP
PD03	6/03/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1925 HR, 8353 LP
PD03	7/03/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1925 HR, 8358 LP
PD03	7/03/2015	202176	Pito jaw housing cracking up, check and adjusted	Breakdown		1925 HR, 8358 LP
PD03	8/03/2015	202182	Adjusted drifter slides.	Corrective Maintenance		1925 HR, 8362 LP
PD03	8/03/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1925 HR, 8362 LP
PD03	9/03/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1925 HR, 8362 LP
PD03	10/03/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	10/03/2015	202205	Pito cylinder alignment faultReplaced 2 x pito cyli	Breakdown		
PD03	10/03/2015	202200	Replaced drifter slide & adjusted alignmentReplac	Breakdown		
PD03	11/03/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1927 HR, 8374 LP
PD03	11/03/2015	202214	HV electric motor shorted (Overloaded)Replaced	Breakdown		1927 HR, 8374 LP
PD03	11/03/2015	202221	Repaired rod handler	Breakdown		1927 HR, 8374 LP
PD03	11/03/2015	202213	Rig going into anti jam (Found u/s bit)Aligned piti	Corrective Maintenance		1927 HR, 8374 LP
PD03	12/03/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1930 HR, 8379 LP
PD03	13/03/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1930 HR, 8381 LP
PD03	13/03/2015	202310	Repaired spot lightReplaced blown hose	Corrective Maintenance		1930 HR, 8381 LP
PD03	14/03/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1930 HR, 8388 LP
PD03	15/03/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	16/03/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1932 HR, 8400 LP
PD03	16/03/2015	202328	Low water pressure faultBlocked water hose	Breakdown		1932 HR, 8400 LP
PD03	17/03/2015	202269	2 Weekly Service - Atlas 1257MEMS PM TASK 374	Preventative Maintenance		1933 HR, 8401 LP
PD03	18/03/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1935 HR, 8404 LP
PD03	19/03/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1937 HR, 8404 LP
PD03	19/03/2015	202423	Repaired clino sensor plug X 10	Breakdown		1937 HR, 8404 LP
PD03	20/03/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1938 HR, 8409 LP
PD03	21/03/2015	202435	Change rod arm assy	Breakdown		1940 HR, 8411 LP
PD03	21/03/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1940 HR, 8411 LP
PD03	21/03/2015	202437	Finish installing - set up rod gripper arm assy	Breakdown		1940 HR, 8411 LP
PD03	21/03/2015	202439	Replace new front rod gripper cylinder - blown ou	Breakdown		1940 HR, 8411 LP
PD03	22/03/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	23/03/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	23/03/2015	202466	Replace feed rope (Pull) & adjust rod alignment	Breakdown		
PD03	23/03/2015	202447	Replaced blown hose & tied up clip on	Breakdown		
PD03	23/03/2015	202448	Replaced blown hose & tightened rod handler	Breakdown		
PD03	24/03/2015	202474	Re-fitted steering pin	Breakdown		
PD03	25/03/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter

PD03	25/03/2015	202479	Replaced 2 x blown hoses	Breakdown		
PD03	25/03/2015	202478	Tighten lose rod handlerStraighten carousel plate	Breakdown		
PD03	26/03/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1945 HR, 8427 LP
PD03	26/03/2015	202549	Drain water out of hydraulic tank	Breakdown		1945 HR, 8427 LP
PD03	26/03/2015	202544	Replaced strapping bolt & Rod handler cylinder	Breakdown		1945 HR, 8427 LP
PD03	27/03/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	28/03/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1947 HR, 8437 LP
PD03	29/03/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1948 HR, 8444 LP
PD03	30/03/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1949 HR, 8457 LP
PD03	31/03/2015	202513	2 Weekly Service - Atlas 1257MEMS PM TASK 374	Preventative Maintenance		1949 HR
PD03	31/03/2015	202592	Replaced hydraulic coolerLeaking water in to hydri	Corrective Maintenance		1949 HR
PD03	1/04/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	2/04/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1952 HR, 8466 LP
PD03	2/04/2015	202669	Re Seal Flushing Head	Breakdown		1952 HR, 8466 LP
PD03	2/04/2015	202601	Repair water leaking out tele tail hole in drifterFlu	Breakdown		1952 HR, 8466 LP
PD03	2/04/2015	202668	Replaced -12 hose.	Breakdown		1952 HR, 8466 LP
PD03	3/04/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1953 HR, 8466 LP
PD03	4/04/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	4/04/2015	202709	No Boom movementsPup load coil full of corrosion	Breakdown		
PD03	4/04/2015	202693	Re wire pump load coilNew jaw and pin for gripper	Breakdown		
PD03	5/04/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	6/04/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1953 HR, 8475 LP
PD03	6/04/2015	202719	Replaced blown hose & repaired water leak	Breakdown		1953 HR, 8475 LP
PD03	7/04/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	8/04/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1954 HR, 8496 LP
PD03	8/04/2015	202842	Remounted Pito cylinder & check rattling noise	Breakdown		1954 HR, 8496 LP
PD03	9/04/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1955 HR, 8500 LP
PD03	9/04/2015	202840	Replaced flushing head seals	Breakdown		1955 HR, 8500 LP
PD03	9/04/2015	202863	Stripped Drifter to repair flushing housingAdjusted	Breakdown		1955 HR, 8500 LP
PD03	10/04/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1955 HR, 8503 LP
PD03	11/04/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1955 HR, 8508 LP
PD03	11/04/2015	202877	Fit new clino cable & calibrate	Damage		1955 HR, 8508 LP
PD03	12/04/2015	202883	Clino fault C/O X10 sensor	Breakdown		1957 HR, 8512 LP
PD03	12/04/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1957 HR, 8512 LP
PD03	13/04/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1959 HR, 8515 LP
PD03	14/04/2015	202645	2 Weekly Service - Atlas 1257MEMS PM TASK 374	Preventative Maintenance		1961 HR, 8520 LP
PD03	14/04/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1961 HR, 8520 LP
PD03	14/04/2015	202899	Replaced blown high pressure Accumulator. Rega	Breakdown		1961 HR, 8520 LP
PD03	15/04/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1963 HR, 8522 LP
PD03	16/04/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1963 HR, 8526 LP
PD03	17/04/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1967 HR, 8535 LP
PD03	18/04/2015	202924	-6 hose	Breakdown		1968 HR, 8537 LP
PD03	18/04/2015	202921	C/O Hyd pump load coil	Breakdown		1968 HR, 8537 LP
PD03	18/04/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1968 HR, 8537 LP
PD03	18/04/2015	202946	Lights & fire supression faults all night	Breakdown		1968 HR, 8537 LP
PD03	19/04/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1969 HR, 8547 LP
PD03	20/04/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1970 HR, 8551 LP
PD03	20/04/2015	202953	Replaced blown hose & replaced gripper jawAdjus	Breakdown		1970 HR, 8551 LP
PD03	21/04/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1971 HR, 8558 LP
PD03	21/04/2015	202964	Remove & reseal LH accumulator	Breakdown		1971 HR, 8558 LP
PD03	22/04/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1971 HR, 8562 LP
PD03	23/04/2015	203047	Accumulator fault (Gas) & 2 x blown hoses	Breakdown		1973 HR, 8568 LP
PD03	23/04/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1973 HR, 8568 LP
PD03	24/04/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1974 HR, 8570 LP
PD03	25/04/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1975 HR, 8571 LP
PD03	26/04/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1975 HR
PD03	27/04/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1976 HR, 8572 LP
PD03	27/04/2015	203078	Freed up air mist switch	Breakdown		1976 HR, 8572 LP
PD03	28/04/2015	203009	2 Weekly Service - Atlas 1257MEMS PM TASK 374	Preventative Maintenance		1977 HR
PD03	28/04/2015	203092	Cylinder - RH Front Jack Leg Change out on cond	Component Change out		1977 HR
PD03	28/04/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1977 HR
PD03	28/04/2015	203097	Replaced ramp up coil & harness (Fuse blown)Spi	Breakdown		1977 HR
PD03	28/04/2015	203073	Straighten carousel drum & replaced blown fitting	Breakdown		1977 HR
PD03	29/04/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1980 HR, 8573 LP
PD03	30/04/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1981 HR, 8579 LP
PD03	1/05/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	1/05/2015	203214	Replaced u/s feed rope & bolt	Breakdown		
PD03	2/05/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	2/05/2015	203243	Fit new spot light	Preventative Maintenance		
PD03	3/05/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	4/05/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1982 HR, 8609 LP
PD03	4/05/2015	203269	Levers kicking out (Percusion & Feed)Blanked off	Breakdown		1982 HR, 8609 LP
PD03	4/05/2015	203256	Replaced blown hose	Breakdown		1982 HR, 8609 LP
PD03	4/05/2015	203257	Replaced rebuit kick out	Breakdown		1982 HR, 8609 LP
PD03	5/05/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1986 HR, 8613 LP
PD03	6/05/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1986 HR, 8618 LP

PD03	6/05/2015	203288	Replaced clip on bottom LHReplaced pito bolt Ro	Breakdown		1986 HR, 8618 LP
PD03	7/05/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1987 HR, 8621 LP
PD03	8/05/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1988 HR, 8625 LP
PD03	9/05/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1988 HR, 8625 LP
PD03	10/05/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1990 HR, 8632 LP
PD03	10/05/2015	203398	Replaced X7 clino sensor & calibrate	Breakdown		1990 HR, 8632 LP
PD03	11/05/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1991 HR, 8638 LP
PD03	12/05/2015	203178	2 Weekly Service - Atlas 1257MEMS PM TASK 374	Preventative Maintenance	Replace startermotor poer cable, Replaced fire s	1992 HR
PD03	12/05/2015	203497	Cylinder - RH Rear Jack Leg Changeout on condit	Component Change out		1992 HR
PD03	12/05/2015	203008	Replace zoom keys (Check stock Surface store Pi	Preventative Maintenance		1992 HR
PD03	13/05/2015	203420	No full percussionCT1 block replaced positioning s	Breakdown		1992 HR, 8643 LP
PD03	13/05/2015	203427	Replace X 8 clino sensorReplaced blown hose	Breakdown		1992 HR, 8643 LP
PD03	14/05/2015	203429	Broken hose tree & Bent rod handler	Breakdown		1993 HR, 8645 LP
PD03	14/05/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1993 HR, 8645 LP
PD03	14/05/2015	203500	Power pack elec motor over loadAdjusted all pres	Breakdown		1993 HR, 8645 LP
PD03	14/05/2015	203511	Replaced Hoses x6	Breakdown		1993 HR, 8645 LP
PD03	15/05/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1996 HR, 8651 LP
PD03	16/05/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	18/05/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1997 HR, 8667 LP
PD03	18/05/2015	203545	Removed filter cart (Water out of system)	Corrective Maintenance		1997 HR, 8667 LP
PD03	19/05/2015	203568	Cylinder - Feed Extension Changeout (On Conditio	Breakdown		1998 HR, 8671 LP
PD03	19/05/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1998 HR, 8671 LP
PD03	20/05/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1999 HR, 8676 LP
PD03	20/05/2015	203572	Repaired water leak on rear fitting (Water all over)	Breakdown		1999 HR, 8676 LP
PD03	20/05/2015	203584	Replaced pito bolt & 2 x mex head boltReplaced t	Breakdown		1999 HR, 8676 LP
PD03	21/05/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	1999 HR, 8678 LP
PD03	21/05/2015	203651	Fitted full percussion throttle valveAdjusted all CT	Breakdown		1999 HR, 8678 LP
PD03	21/05/2015	203648	Repaired rear stinger	Breakdown		1999 HR, 8678 LP
PD03	22/05/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2000 HR, 8683 LP
PD03	22/05/2015	203661	Repair rod changer arm & PITO jaw	Breakdown		2000 HR, 8683 LP
PD03	22/05/2015	203660	Reseal flushing head	Breakdown		2000 HR, 8683 LP
PD03	23/05/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2000 HR, 8687 LP
PD03	23/05/2015	203668	Oil leak on drifter @ shuttle cap	Breakdown	Replace shuttle cap O ring & 2 X -12 hoses	2000 HR, 8687 LP
PD03	23/05/2015	203673	Remove blown return accumulator assy	Breakdown	Removed assy as it causes hose vibration	2000 HR, 8687 LP
PD03	24/05/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2001 HR, 8694 LP
PD03	25/05/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2001 HR, 8699 LP
PD03	25/05/2015	203687	Work on percussion fault (Looses full percussion)Re	Breakdown		2001 HR, 8699 LP
PD03	26/05/2015	203475	3 Monthly Service - ATLAS 1257MEMS PM TASK 4	Preventative Maintenance		2003 HR, 8702 LP
PD03	26/05/2015	203705	Blown hoses x 2Air water fault (Oring missing) C	Breakdown		2003 HR, 8702 LP
PD03	27/05/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2005 HR, 8702 LP
PD03	27/05/2015	203719	Percussion faultReplaced check valve robbing oil b	Breakdown		2005 HR, 8702 LP
PD03	27/05/2015	203802	Replaced Rear Stinger & Feed rope adjuster	Breakdown		2005 HR, 8702 LP
PD03	27/05/2015	203799	Replaced starter motor	Breakdown		2005 HR, 8702 LP
PD03	28/05/2015	203813	Air flushing fault, fread up check valve at rear of	Breakdown		2007 HR, 8706 LP
PD03	28/05/2015	203811	Replaced blown dash hose	Breakdown		2007 HR, 8706 LP
PD03	28/05/2015	203812	Replaced flushing water seals	Breakdown		2007 HR, 8706 LP
PD03	29/05/2015	203822	Rear Stinger not working properly, found impulse	Breakdown		
PD03	30/05/2015	203830	Fault finding on Park brake, couldn't get fault to c	Breakdown		
PD03	30/05/2015	203831	Replaced Blown hose	Breakdown		
PD03	30/05/2015	203837	Tighten lose bolts on LH Control panel, panel was	Breakdown		
PD03	1/06/2015	203843	Check p/brake coming on replaced K10 relayChec	Corrective Maintenance		
PD03	1/06/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	1/06/2015	203841	Replaced Mux head sealsReplaced shuttle valve c	Breakdown		
PD03	2/06/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	2/06/2015	203855	Replaced blown hoses	Breakdown		
PD03	3/06/2015	203935	Replace hose reel	Breakdown		
PD03	4/06/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	5/06/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2019 HR, 8752 LP
PD03	6/06/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2019 HR, 8758 LP
PD03	6/06/2015	203953	PITO jaws not gripping properly	Breakdown	C/O check valve & pressure red valve for PITO j	2019 HR, 8758 LP
PD03	6/06/2015	203960	Refitted feed rope	Breakdown		2019 HR, 8758 LP
PD03	6/06/2015	203950	Replace rear return rope	Breakdown		2019 HR, 8758 LP
PD03	7/06/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2019 HR, 8763 LP
PD03	7/06/2015	203973	Repaired water flushingReplaced u/s hose	Breakdown		2019 HR, 8763 LP
PD03	8/06/2015	203757	2 Weekly Service - Atlas 1257MEMS PM TASK 374	Preventative Maintenance		2019 HR, 8768 LP
PD03	8/06/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2019 HR, 8768 LP
PD03	8/06/2015	203992	Repaired leak in dash & tightened loose fitting	Breakdown		2019 HR, 8768 LP
PD03	9/06/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2023 HR, 8771 LP
PD03	10/06/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2024 HR, 8771 LP
PD03	10/06/2015	204045	Repair fuel gauge or order parts to repair	Corrective Maintenance		2024 HR, 8771 LP
PD03	11/06/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2025 HR, 8777 LP
PD03	11/06/2015	204077	Replaced lube regulator, lost percussion	Breakdown		2025 HR, 8777 LP
PD03	12/06/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2027 HR, 8782 LP
PD03	13/06/2015	204098	Cylinder - Stinger Changeout on conditionReplace	Breakdown		
PD03	13/06/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	14/06/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter

PD03	15/06/2015	204126	Replaced broken off Jack Level	Breakdown		2029 HR, 8792 LP
PD03	16/06/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	17/06/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2031 HR, 8804 LP
PD03	17/06/2015	204230	Replaced blown water hoseReplcaed Drifter shutt	Breakdown		2031 HR, 8804 LP
PD03	18/06/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	19/06/2015	204246	Cylinder - LH Front Jack Leg Change out on condi	Component Change out		2032 HR, 8808 LP
PD03	19/06/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2032 HR, 8808 LP
PD03	20/06/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2032 HR, 8809 LP
PD03	20/06/2015	204259	Fitted tap to stop LH jack creeping	Breakdown		2032 HR, 8809 LP
PD03	21/06/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2033 HR, 8813 LP
PD03	22/06/2015	204025	2 Weekly Service - Atlas 1257MEMS PM TASK 37	Preventative Maintenance		2034 HR, 8818 LP
PD03	22/06/2015	205017	Repair oil leak	Breakdown		2034 HR, 8818 LP
PD03	23/06/2015	205110	Make up x2 hoses for Pos1 Jack Leg	Breakdown		2035 HR, 8822 LP
PD03	23/06/2015	205116	Top Hat Locating pin not located correctlybelted i	Breakdown		2035 HR, 8822 LP
PD03	24/06/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2038 HR, 8826 LP
PD03	24/06/2015	205254	Replace fitting 90deg	Breakdown		2038 HR, 8826 LP
PD03	25/06/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2040 HR, 8833 LP
PD03	25/06/2015	204264	Replace Jack leg DCV complete bank3128 2090 7	Corrective Maintenance		2040 HR, 8833 LP
PD03	26/06/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	26/06/2015	205201	earthing problem-when jacks up earth would cut	Corrective Maintenance		
PD03	27/06/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	28/06/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	29/06/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2040 HR, 8842 LP
PD03	29/06/2015	205268	Replace blown hose.	Breakdown		2040 HR, 8842 LP
PD03	30/06/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2042 HR, 8848 LP
PD03	1/07/2015	205365	Simba pilot fault	Breakdown		2044 HR, 8856 LP
PD03	2/07/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2045 HR, 8862 LP
PD03	2/07/2015	205398	Fit rod arm sheer boltreplace pito jaw fitting adju	Breakdown		2045 HR, 8862 LP
PD03	2/07/2015	205400	Un-jam rod arm (rock stuck)	Breakdown		2045 HR, 8862 LP
PD03	3/07/2015	205417	change out damaged feed cylinder fittings	Breakdown		2045 HR
PD03	3/07/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2045 HR
PD03	3/07/2015	205413	Replace blown hose	Damage	C/O Blown hose -6 hose 2.7m long	2045 HR
PD03	3/07/2015	205407	Replace flushing head seals	Breakdown	Replace flashing seals	2045 HR
PD03	4/07/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2045 HR, 8870 LP
PD03	5/07/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2048 HR, 8877 LP
PD03	6/07/2015	205466	Cylinder - Stinger Changeout on conditionReplace	Breakdown		2048 HR, 8889 LP
PD03	6/07/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2048 HR, 8889 LP
PD03	7/07/2015	205076	2 Weekly Service - Atlas 1257MEMS PM TASK 37	Preventative Maintenance		2048 HR
PD03	7/07/2015	205547	Replaced dowerty washer & tightened lose fitting	Breakdown		2048 HR
PD03	8/07/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	9/07/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2053 HR, 8892 LP
PD03	9/07/2015	205576	Noisy hyd pump. Pump checked for efficiency.	Breakdown		2053 HR, 8892 LP
PD03	11/07/2015	205638	Pitto Jaws not holding	Breakdown		
PD03	15/07/2015	205725	Decommissioning machine remove extras etc.	Preventative Maintenance		
PD03	16/07/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	18/07/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	19/07/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2057 HR, 8900 LP
PD03	20/07/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	13/08/2015	206707	Park brake would not releaseWiring in dash, on c	Breakdown		
PD03	14/08/2015	206740	2 Faults, 24v CB tripping was US lightWater pump	Breakdown		
PD03	14/08/2015	206729	Repair all faults before rig goes back to work	Breakdown	Refit lube bottle & bleed lube circuit & test Refit water pump motor	
PD03	16/08/2015	206759	adjust rod alignment	Corrective Maintenance		
PD03	16/08/2015	206761	c/o blown -6 hose	Breakdown		
PD03	16/08/2015	206762	change out blown hyd hose	Breakdown		
PD03	16/08/2015	206758	rev feed and rotation fault	Breakdown		
PD03	18/08/2015	206913	Adjust spot light bracket and fit spot light.	Corrective Maintenance		
PD03	18/08/2015	206923	rod handler repairs	Breakdown		
PD03	20/08/2015	206984	Find oil leak and C/O -10 hoseTop up oil.	Breakdown		2069 HR, 8914 LP
PD03	21/08/2015	206985	C/O drifter shuttle o-ring.	Corrective Maintenance		2069 HR, 8917 LP
PD03	21/08/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2069 HR, 8917 LP
PD03	22/08/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	23/08/2015	207028	2 Weekly Service - Atlas 1257MEMS PM TASK 37	Preventative Maintenance		
PD03	24/08/2015	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2071 HR, 8919 LP
PD03	1/09/2015	206825	2 Weekly Service - Atlas 1257MEMS PM TASK 37	Preventative Maintenance		
PD03	30/05/2016	217563	Weld on transferr tubes	Corrective Maintenance		
PD03	31/05/2016	217790	Hydraulic temp fault	Breakdown		
PD03	1/06/2016	217586	Low Hydraulic Oil light On?No sensor wired into r	Breakdown		2077 HR, 8926 LP
PD03	1/06/2016	217774	threading fault	Breakdown		2077 HR, 8926 LP
PD03	2/06/2016	217792	cable reel fault	Breakdown		2079 HR, 8926 LP
PD03	2/06/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2079 HR, 8926 LP
PD03	2/06/2016	217799	Replace Mex head seals.	Corrective Maintenance		2079 HR, 8926 LP
PD03	3/06/2016	217815	Park brake not releasing. (jumbo cable in reel too	Corrective Maintenance		2083 HR, 8943 LP
PD03	6/06/2016	217832	c/o hyd temp switch	Breakdown		
PD03	6/06/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	6/06/2016	217826	Inspect Drifter making oil.Used 40 ltrs a shift.	Breakdown		
PD03	7/06/2016	217930	\$replace LH canopy fitting dowdy washer.	Corrective Maintenance		2083 HR, 8960 LP

PD03	7/06/2016	217858	Adjust Rod handlers.	Corrective Maintenance		2083 HR, 8960 LP
PD03	7/06/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2083 HR, 8960 LP
PD03	7/06/2016	217859	Replace Rotation Motor Hose (stuck in Backs).	Breakdown		2083 HR, 8960 LP
PD03	8/06/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2085 HR, 8965 LP
PD03	9/06/2016	217943	C/O -8 hose.	Corrective Maintenance		2085 HR, 8965 LP
PD03	10/06/2016	217847	2 Weekly Electrical Service - Drills23-105001-01.p	Preventative Maintenance		2085 HR, 8965 LP
PD03	10/06/2016	218000	change drifter	Breakdown		2085 HR, 8965 LP
PD03	13/06/2016	218001	percussion at idle faults	Corrective Maintenance		
PD03	15/06/2016	218048	C/O U/S fitting on drifter and hose fitting.	Breakdown		2087 HR, 8970 LP
PD03	15/06/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2087 HR, 8970 LP
PD03	15/06/2016	218047	Swap rotation hoses around.	Breakdown		2087 HR, 8970 LP
PD03	16/06/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2087 HR, 8971 LP
PD03	20/06/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	20/06/2016	218201	Refit Retuen Rope.	Breakdown		
PD03	21/06/2016	218502	change rope, fit new hoses	Breakdown		2089 HR, 8973 LP
PD03	21/06/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2089 HR, 8973 LP
PD03	21/06/2016	218302	Install Clyno Dash - Check Calibration.	Breakdown		2089 HR, 8973 LP
PD03	22/06/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2090 HR, 8978 LP
PD03	22/06/2016	218546	Replace missing rod arm jaw.	Breakdown		2090 HR, 8978 LP
PD03	22/06/2016	218523	Tighten loose front centraliser bolts & clean sting	Breakdown		2090 HR, 8978 LP
PD03	23/06/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2090 HR, 8989 LP
PD03	23/06/2016	218569	recoil front centraliser threads weld support	Breakdown		2090 HR, 8989 LP
PD03	24/06/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2092 HR, 8993 LP
PD03	25/06/2016	218596	Broken fitting.	Breakdown		2093 HR, 9004 LP
PD03	27/06/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	27/06/2016	218617	Replace broken fittings and damaged hose.	Breakdown		
PD03	28/06/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2095 HR, 9014 LP
PD03	29/06/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2096 HR, 9017 LP
PD03	29/06/2016	218653	ran out of fuel, fill up and bleded system	Breakdown		2096 HR, 9017 LP
PD03	30/06/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2096 HR, 9018 LP
PD03	1/07/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2098 HR, 9029 LP
PD03	4/07/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2098 HR, 9029 LP
PD03	4/07/2016	218694	feed fault	Breakdown		2098 HR, 9029 LP
PD03	5/07/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2100 HR, 9034 LP
PD03	5/07/2016	218704	repair leak on fops	Breakdown		2100 HR, 9034 LP
PD03	12/07/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2101 HR, 9036 LP
PD03	13/07/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	14/07/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2102 HR, 9039 LP
PD03	15/07/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2102 HR, 9045 LP
PD03	22/07/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	22/07/2016	224388	Replace missing Percussion Lever.	Corrective Maintenance		
PD03	27/07/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2105 HR, 9064 LP
PD03	27/07/2016	224534	Screen loosing Back Light?Split module, blow out	Corrective Maintenance		2105 HR, 9064 LP
PD03	28/07/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	29/07/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2106 HR, 9067 LP
PD03	1/08/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2106 HR, 9067 LP
PD03	2/08/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	3/08/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2107 HR, 9073 LP
PD03	3/08/2016	224596	Replace P-Brake Switch.	Corrective Maintenance		2107 HR, 9073 LP
PD03	4/08/2016	224655	c/o broken shank	Breakdown		
PD03	4/08/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	4/08/2016	224670	Repair X11 Clyno sensor wiring.Recalibrate Clyno	Corrective Maintenance		
PD03	4/08/2016	224671	Replace Charge Valve HP Accumulator.Re Gas Acc	Breakdown		
PD03	4/08/2016	224674	Replace zoom cylinder fitting dowdy washers.	Corrective Maintenance		
PD03	5/08/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2108 HR, 9083 LP
PD03	11/08/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2109 HR, 9085 LP
PD03	11/08/2016	224822	Jumpstart.(Isolator was left on)	Breakdown		2109 HR, 9085 LP
PD03	12/08/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2110 HR, 9089 LP
PD03	16/08/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	18/08/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2112 HR, 9100 LP
PD03	25/08/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2112 HR
PD03	26/08/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2114 HR, 9111 LP
PD03	29/08/2016	225159	re-calibrate clino and fix oil leaks.	Breakdown		
PD03	29/08/2016	225156	Replace broken -6 Pito Jaw fitting.	Breakdown		
PD03	5/09/2016	225318	broken fitting on rotation motor/c/o damaged -8 fi	Breakdown		
PD03	5/09/2016	225320	Park brake not releasing cable overwound	Breakdown		
PD03	6/09/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2116 HR, 9128 LP
PD03	7/09/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2116 HR, 9128 LP
PD03	7/09/2016	225405	Water pump not working/repair wirring harness to	Breakdown		2116 HR, 9128 LP
PD03	8/09/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2117 HR, 9138 LP
PD03	9/09/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2117 HR, 9142 LP
PD03	11/09/2016	225437	c/o snapped fitting in rotation motor	Breakdown		
PD03	12/09/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2117 HR, 9158 LP
PD03	13/09/2016	225451	Assist Opp with Jammed Rods.Broken string fell t	Breakdown		
PD03	13/09/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	15/09/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2119 HR, 9166 LP

PD03	16/09/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2120 HR, 9168 LP
PD03	19/09/2016	225623	c/o - 6 hose + 90 fitting	Breakdown		
PD03	19/09/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	20/09/2016	225642	change blown grease hose	Breakdown		2121 HR, 9179 LP
PD03	21/09/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2121 HR, 9191 LP
PD03	22/09/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2121 HR, 9194 LP
PD03	26/09/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	26/09/2016	225757	not starting, wires shorting, change flushing head	Breakdown		
PD03	27/09/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2124 HR, 9202 LP
PD03	29/09/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	30/09/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2125 HR, 9212 LP
PD03	3/10/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	4/10/2016	226003	c/o -6 hose	Breakdown		
PD03	4/10/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	4/10/2016	226010	jod grippers not working properly	Breakdown		
PD03	4/10/2016	226023	rig triped found blown fuse in central jb found hy	Breakdown		
PD03	4/10/2016	226004	snapped feed ropec/o feed rope	Breakdown		
PD03	5/10/2016	226028	Both pito jaw clys u/s.	Breakdown		2126 HR, 9221 LP
PD03	5/10/2016	226017	c/o 2x rusted out water fittings	Breakdown		2126 HR, 9221 LP
PD03	5/10/2016	226021	c/o hydraulic filler pump	Breakdown		2126 HR, 9221 LP
PD03	5/10/2016	226016	check gripper arm pressures, holding at 220 bar	Breakdown		2126 HR, 9221 LP
PD03	5/10/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2126 HR, 9221 LP
PD03	6/10/2016	226039	c/o -6 hose under dash	Breakdown		2126 HR, 9232 LP
PD03	6/10/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2126 HR, 9232 LP
PD03	6/10/2016	226050	fix water pump	Breakdown		2126 HR, 9232 LP
PD03	6/10/2016	226067	jump start	Breakdown		2126 HR, 9232 LP
PD03	7/10/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2126 HR, 9236 LP
PD03	10/10/2016	226089	adjust rod handlers	Corrective Maintenance		2127 HR, 9257 LP
PD03	10/10/2016	226073	Blown Perc Hose.Re-wrap loom	Breakdown		2127 HR, 9257 LP
PD03	10/10/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2127 HR, 9257 LP
PD03	10/10/2016	226071	Repair Backing Plate Bracket to Rail.	Breakdown		2127 HR, 9257 LP
PD03	11/10/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2127 HR, 9257 LP
PD03	12/10/2016	226094	C/O blown hose under dash	Breakdown		2128 HR, 9257 LP
PD03	12/10/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2128 HR, 9257 LP
PD03	13/10/2016	226139	Cylinder - Rod Handler Arms Changeout on condi	Component Change out	Replaced Both Rod Handlers worn out !	2128 HR, 9260 LP
PD03	13/10/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2128 HR, 9260 LP
PD03	18/10/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	18/10/2016	226230	repair rear plate on rail.	Breakdown		
PD03	19/10/2016	226178	Weld backing plate mount back on.Repair grease	Breakdown		2130 HR, 9276 LP
PD03	20/10/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2131 HR, 9281 LP
PD03	21/10/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2131 HR, 9293 LP
PD03	21/10/2016	226255	Reassemble Pito Clamp Cyl.	Breakdown		2131 HR, 9293 LP
PD03	23/10/2016	226259	Pump not stroking up to full pressureNo boom m	Breakdown		
PD03	31/10/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	31/10/2016	226434	Motor overloading on main pump. Overcurrent ov	Breakdown		
PD03	1/11/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2132 HR, 9295 LP
PD03	2/11/2016	226505	Blown Pito hose, stuck in backs.	Breakdown		2133 HR, 9299 LP
PD03	2/11/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2133 HR, 9299 LP
PD03	3/11/2016	226509	replace missing pitto jaw mounting bolts	Breakdown		2133 HR, 9314 LP
PD03	4/11/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2134 HR, 9315 LP
PD03	6/11/2016	226539	Rods getting caught in magazine.	Corrective Maintenance		
PD03	7/11/2016	226555	Blown carrier hose.Temporary hose run to front b	Breakdown		
PD03	7/11/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	8/11/2016	226565	C/O 3x hoses under carrier.	Breakdown		2134 HR, 9318 LP
PD03	8/11/2016	226558	Cylinder - Rod Handler Arms Changeout on condi	Breakdown	Replaced Both Rod Handlers worn out !	2134 HR, 9318 LP
PD03	9/11/2016	226708	C/o damaged hyd fittings.	Breakdown		2135 HR, 9321 LP
PD03	9/11/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2135 HR, 9321 LP
PD03	10/11/2016	226722	C/o blown drifter hose.	Breakdown		2135 HR, 9332 LP
PD03	10/11/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2135 HR, 9332 LP
PD03	10/11/2016	226712	replace 2x missing bolts + c/o damaged rod retai	Damage		2135 HR, 9332 LP
PD03	11/11/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2136 HR, 9345 LP
PD03	14/11/2016	226767	Blown lp accumulator. U/s charge valve.	Breakdown		
PD03	14/11/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	14/11/2016	226745	Opp Ran out of Fuel.Fill and Prime up.	Damage		
PD03	14/11/2016	226739	weld up broken rear rod handler stopperremove v	Breakdown		
PD03	15/11/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2136 HR, 9353 LP
PD03	15/11/2016	226777	parkbrake faultpull out trailing cable	Breakdown		2136 HR, 9353 LP
PD03	16/11/2016	226791	c/o -12 perc hose	Breakdown		2136 HR, 9353 LP
PD03	16/11/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2136 HR, 9353 LP
PD03	17/11/2016	226614	2 Weekly Electrical Service - Drills 23-105001-01	Preventative Maintenance		2137 HR, 9362 LP
PD03	18/11/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	18/11/2016	226875	laser repairsrepair l/h/s broken power wiring to la	Breakdown		
PD03	21/11/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	22/11/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2139 HR, 9370 LP
PD03	23/11/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2139 HR, 9373 LP
PD03	24/11/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2139 HR, 9380 LP

PD03	24/11/2016	226987	Repair hose leak under carrier.	Breakdown		2139 HR, 9380 LP
PD03	25/11/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2141 HR, 9384 LP
PD03	26/11/2016	227012	All boom functions fault.U/S ramp up coil lead.	Breakdown		
PD03	28/11/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2142 HR, 9387 LP
PD03	28/11/2016	227024	motor overload faultreset button on a-cabinet	Breakdown		2142 HR, 9387 LP
PD03	30/11/2016	227104	Clino fault.Clean x12 cable and calibrate.	Breakdown		
PD03	30/11/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	1/12/2016	227108	c/o blown hyd hosec/o loom hose !!6 2.5 m rewre	Breakdown		2143 HR, 9394 LP
PD03	1/12/2016	227173	C/O percussion lever.	Breakdown		2143 HR, 9394 LP
PD03	1/12/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2143 HR, 9394 LP
PD03	7/12/2016	227105	Tighten front rod arm mounting bolts.	Breakdown		2143 HR, 9394 LP
PD03	2/12/2016	227175	Remove 2x broken bolts on pito jaws.	Breakdown		2143 HR, 9400 LP
PD03	2/12/2016	227177	Replace snapped pito jaw fitting.	Breakdown		2143 HR, 9400 LP
PD03	2/12/2016	227178	Re-wire ramp up coil deutz plug.	Breakdown		2143 HR, 9400 LP
PD03	5/12/2016	227226	X 12 required recalibrating	Corrective Maintenance		
PD03	7/12/2016	227229	clino faultsjunction box with x12 in it full of water	Breakdown	Awaiting Clino sensor	2146 HR, 9401 LP
PD03	9/12/2016	227350	Monthly Service - Atlas 1257MEMS PM TASK 374	Preventative Maintenance		
PD03	11/12/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	13/12/2016	227410	c/o broken hdy fitting at pito jaws	Damage		2150 HR, 9403 LP
PD03	13/12/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2150 HR, 9403 LP
PD03	14/12/2016	227444	C/O x8 clino cable.	Breakdown		2152 HR, 9408 LP
PD03	14/12/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2152 HR, 9408 LP
PD03	14/12/2016	227503	tighten rod arm mounting bolts	Breakdown		2152 HR, 9408 LP
PD03	15/12/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2152 HR, 9414 LP
PD03	15/12/2016	227508	Fit Feed Cyl Spacer from Old Cyl (125mm).Drifter	Corrective Maintenance		2152 HR, 9414 LP
PD03	15/12/2016	227500	Front rod bin faulttighten up front rod bin mountir	Breakdown		2152 HR, 9414 LP
PD03	16/12/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2155 HR, 9421 LP
PD03	21/12/2016	227678	C/O 1x battery.	Breakdown		
PD03	21/12/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	22/12/2016	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	3/01/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	4/01/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	5/01/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	6/01/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	10/01/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	10/01/2018	235184	Replace Doudy Washers on Feed Fitings.	Breakdown		
PD03	11/01/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	11/01/2018	235234	P-Brake fault?Came good.	Breakdown		
PD03	12/01/2018	234934	6 Monthly Service - Atlas 1257MEMS PM TASK 42	Preventative Maintenance		
PD03	15/01/2018	235276	c/o rod hander arm and straighten bent plate	Breakdown		442 LP
PD03	15/01/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	442 LP
PD03	15/01/2018	235272	fire supression fault, clean out pressure switch pli	Breakdown		442 LP
PD03	15/01/2018	235271	jumpstart and c/o alternator	Breakdown		442 LP
PD03	16/01/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	17/01/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2315 HR, 446 LP
PD03	18/01/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	19/01/2018	235523	Cylinder - Feed Thrust Changeout on condition	Component Change out		2315 HR, 455 LP
PD03	19/01/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2315 HR, 455 LP
PD03	20/01/2018	235409	Replace missing Feed Cyl Buffer.Tighten Loose Fe	Corrective Maintenance		
PD03	20/01/2018	235405	Rod handlers colliding with Profile?	Breakdown		
PD03	21/01/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	23/01/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	23/01/2018	235451	Reseal Feed Cylinder.	Breakdown		
PD03	23/01/2018	235452	Retrofit Feed Fitting as Nil Stock.	Breakdown		
PD03	24/01/2018	235520	Align Rod Handlers to work predominantly upside	Corrective Maintenance		
PD03	24/01/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	24/01/2018	235455	Replace Stripped Feed adjuster Bolt.	Breakdown		
PD03	25/01/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2315 HR, 467 LP
PD03	26/01/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	29/01/2018	235163	2 Weekly Service - Atlas Simba - DayshiftMEMS P	Preventative Maintenance		
PD03	30/01/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2315 HR, 467 LP
PD03	1/02/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	2/02/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2316 HR, 468 LP
PD03	5/02/2018	235732	Blown Carrier hose.	Breakdown		470 LP
PD03	5/02/2018	235798	c/o -6 hose	Breakdown		470 LP
PD03	5/02/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	470 LP
PD03	5/02/2018	235725	oil leak repairs striped feed cyl fittingstighten lose	Breakdown		470 LP
PD03	5/02/2018	235797	rod alignment adjust reverse threading speed	Breakdown		470 LP
PD03	6/02/2018	235734	Blown Hose.	Breakdown		
PD03	6/02/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	7/02/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	7/02/2018	235815	P-Brake Fault.	Breakdown		
PD03	9/02/2018	235489	2 Weekly Service - Atlas Simba - DayshiftMEMS P	Preventative Maintenance		
PD03	10/02/2018	235855	repair oil leaks, fit rod handler jaw	Breakdown		
PD03	11/02/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	up and adjust drifter
PD03	12/02/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE T	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2316 HR, 472 LP

PD03	13/02/2018	235921	c/o - 6 hose	Breakdown		
PD03	13/02/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	14/02/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2317 HR, 483 LP
PD03	15/02/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	19/02/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	19/02/2018	236011	Tighten loose fitting on feed cylinder	Breakdown		
PD03	20/02/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	20/02/2018	236014	Repair oil leak and tighten feed rope	Corrective Maintenance		
PD03	21/02/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	21/02/2018	236099	Recalibrate Clyno	Breakdown		
PD03	21/02/2018	236093	Replace 9KG fire extinguisher.	Corrective Maintenance		
PD03	22/02/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	22/02/2018	236101	Percussion Kicking out?	Breakdown		
PD03	22/02/2018	236113	Recalibrate Clyno	Breakdown		
PD03	23/02/2018	236131	c/o -8 hose	Breakdown		2317 HR, 505 LP
PD03	23/02/2018	236130	c/o clino sensor	Breakdown		2317 HR, 505 LP
PD03	23/02/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2317 HR, 505 LP
PD03	23/02/2018	236111	Intermittant Shut Down Fault?	Breakdown		2317 HR, 505 LP
PD03	24/02/2018	235775	2 Weekly Service - Atlas Simba - DayshiftMEMS	Preventative Maintenance		
PD03	24/02/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	24/02/2018	236140	shutting down on powerpack	Breakdown		
PD03	25/02/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	26/02/2018	236154	c/o shank	Breakdown		2317 HR, 509 LP
PD03	27/02/2018	236161	adjust rod handlers	Breakdown		
PD03	27/02/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	27/02/2018	236165	fit missing bolt to lever	Breakdown		
PD03	27/02/2018	236164	fit washer to mux head	Breakdown		
PD03	28/02/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	2/03/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	5/03/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	6/03/2018	236305	Build up jaws	Breakdown		2317 HR, 529 LP
PD03	6/03/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2317 HR, 529 LP
PD03	7/03/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2317 HR, 533 LP
PD03	8/03/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	9/03/2018	236074	2 Weekly Service - Atlas Simba - DayshiftMEMS	Preventative Maintenance		
PD03	9/03/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	13/03/2018	236512	C/o blown -8 hose	Breakdown		
PD03	14/03/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	544 LP
PD03	15/03/2018	236513	c/o broken shank alignment adjustment rear rod	Breakdown		1 HR
PD03	16/03/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	551 LP
PD03	17/03/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	17/03/2018	236536	Reseal Feed Releif manifold. Blown O-Ring.	Breakdown		
PD03	19/03/2018	236556	c/o blown hose	Breakdown		560 LP
PD03	19/03/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	560 LP
PD03	20/03/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	23/03/2018	236373	2 Weekly Service - Atlas Simba - DayshiftMEMS	Preventative Maintenance		
PD03	23/03/2018	236679	c/o -6 hose	Breakdown		
PD03	23/03/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	23/03/2018	236678	snapped water cooler fitting, replace with old one	Breakdown		
PD03	24/03/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	25/03/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	27/03/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	28/03/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	28/03/2018	236704	levers kicking out	Breakdown		
PD03	29/03/2018	236792	percussion lever not holding	Corrective Maintenance		562 LP
PD03	31/03/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	31/03/2018	236806	Replace Shank. Flushing head stuck on...Replace	Damage		
PD03	31/03/2018	236835	Replace strapping bolt	Breakdown		
PD03	3/04/2018	236828	Blocked Fuel Filter. Replace, Flush Tank.	Damage		576 LP
PD03	3/04/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	576 LP
PD03	4/04/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	578 LP
PD03	4/04/2018	236861	Percussion lever hard. Found air leak. Reapirod.	Breakdown		578 LP
PD03	4/04/2018	236955	Remove from backs with String up hole.Rebuild P	Breakdown		578 LP
PD03	5/04/2018	236961	c/o blown pump hose	Breakdown		
PD03	5/04/2018	236965	C/o broken -6 90 fitting under dash.	Breakdown		
PD03	5/04/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	5/04/2018	236958	Replace Broken Return Rope.	Damage		
PD03	5/04/2018	236966	Reseal Fushing Head.	Corrective Maintenance		
PD03	5/04/2018	236964	Rod alignment.	Corrective Maintenance		
PD03	6/04/2018	236640	2 Weekly Service - Atlas Simba - DayshiftMEMS	Preventative Maintenance		
PD03	6/04/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	7/04/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	8/04/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	9/04/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	587 LP
PD03	10/04/2018	237007	c/o -8 hose and tighten loose fitting	Breakdown		603 LP
PD03	10/04/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	603 LP

PD03	11/04/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	12/04/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	13/04/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	14/04/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	14/04/2018	237087	Replace damaged hose.	Damage		
PD03	15/04/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	2.5 HR, 619 LP
PD03	16/04/2018	237113	adjust rod arms	Breakdown		
PD03	16/04/2018	237124	C/O flushing head. (rebuild old one).	Corrective Maintenance		
PD03	16/04/2018	237126	Cylinder - Feed Extension Changeout (On Conditio	Component Change out		
PD03	16/04/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	18/04/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	19/04/2018	236930	2 Weekly Service - Atlas Simba - DayshiftMEMS P	Preventative Maintenance		
PD03	19/04/2018	237239	Blown steer hose.	Breakdown		
PD03	19/04/2018	237236	Check rotation speed.Tighten loose fittings.	Corrective Maintenance		
PD03	19/04/2018	237258	Rod Alignment weld gripper pads	Corrective Maintenance		
PD03	20/04/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	21/04/2018	237251	c/o blown hose under rig	Breakdown		
PD03	21/04/2018	237249	c/o leaking jack leg FRH	Breakdown		
PD03	21/04/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	21/04/2018	237250	fire suppression faults eng not starting	Breakdown		
PD03	23/04/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	8 HR, 645 LP
PD03	24/04/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	24/04/2018	237263	fire suppresson shutting eng down chasing partsC	Corrective Maintenance		
PD03	25/04/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	26/04/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	9 HR, 649 LP
PD03	26/04/2018	237350	refit missing pitto jaw bolts	Breakdown		9 HR, 649 LP
PD03	27/04/2018	237361	C/O -6 hose.	Breakdown		10 HR, 654 LP
PD03	27/04/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	10 HR, 654 LP
PD03	28/04/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	29/04/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	30/04/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	11 HR, 657 LP
PD03	1/05/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	13 HR, 658 LP
PD03	1/05/2018	237559	Shut down on over temp, No water?Fix water pur	Corrective Maintenance		13 HR, 658 LP
PD03	2/05/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	3/05/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	3/05/2018	237584	Repair Pito Jaws.	Breakdown		
PD03	4/05/2018	237196	2 Weekly Service - Atlas Simba - DayshiftMEMS P	Preventative Maintenance		
PD03	4/05/2018	237586	Opp lost 2x Flushing head washesrs. Replace.	Damage		
PD03	6/05/2018	237599	c/o - 6 hose	Breakdown		
PD03	8/05/2018	237628	c/o -6 hose	Breakdown		14 HR, 668 LP
PD03	8/05/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	14 HR, 668 LP
PD03	9/05/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	15 HR, 671 LP
PD03	9/05/2018	237688	Rod handlers not gripping? Bypass test Cylinders,	Breakdown		15 HR, 671 LP
PD03	10/05/2018	237696	c/o missing drifter slide ware strip	Corrective Maintenance		15 HR, 673 LP
PD03	10/05/2018	237697	clino fault loose #10 plug removed cleaned tighte	Corrective Maintenance		15 HR, 673 LP
PD03	10/05/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	15 HR, 673 LP
PD03	13/05/2018	237734	Rebuild front rod handler arm.	Breakdown		
PD03	14/05/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	19 HR
PD03	16/05/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	17/05/2018	237474	2 Weekly Service - Atlas Simba - DayshiftMEMS P	Preventative Maintenance		
PD03	17/05/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	17/05/2018	237875	Tighten Feed Rope. No tools on machine?	Corrective Maintenance		
PD03	18/05/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	19/05/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	21/05/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	21 HR
PD03	22/05/2018	237913	adjust rod alignment, drifter slides and threading	Breakdown		
PD03	22/05/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	23/05/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim	22 HR, 678 LP
PD03	24/05/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	26/05/2018	237957	Replace ramp up coil	Breakdown		
PD03	28/05/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	28/05/2018	237962	Remove damaged inner tube of front stingger.	Damage		
PD03	29/05/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	
PD03	29/05/2018	237963	Relace HP accumulator.	Breakdown		
PD03	29/05/2018	237964	Replace rod handler pin.3128 2405 00	Breakdown		
PD03	30/05/2018	X0000003	Daily Service - PD03***PLEASE DO NOT CLOSE	Preventative Maintenance	28/11/2014 8.00 - 9.30. Adjust pito jaws, shim up and adjust drifter	