Tatra WC06 Condition report

Hrs-20,167 Kms 166,936

Safety/Mechanical Integrity

| | <u>Fault</u> | Department Cost |
|----|--|-----------------|
| 1 | Steering 2 light not working wiring fault at box ?? | Maint |
| 2 | Air con fan speed resistor | Maint |
| 3 | AM/FM radio hanging out and doesn't work | Ops |
| 4 | Washer jets blocked | Maint |
| 5 | Dash decals need replacing | Maint |
| 6 | 8x8 light not working ??? | Maint |
| 7 | ABS light not working ?? | Maint |
| 8 | Fuel gauge not working | Maint |
| 9 | RHS seat belt faulty | Ops |
| 10 | LHS door handle lose and screws missing | Ops |
| 11 | Both door lock knobs snapped | Maint |
| 12 | 3x dash vets broken | Maint |
| 13 | Speaker covers missing can only get covers with new speakers | Ops |
| 14 | LHS seat belt U/S | Ops |
| 15 | LHS seat tilt adjustment knob missing | Ops |
| 16 | Steering Colom covers need replacing | Maint |
| 17 | Both door locks are seized and don't work | Maint |
| 18 | Both rubber floor mats need replacing as dangers and ripped | Ops |
| 19 | 6 dash screws missing | Maint |
| 20 | PTO light not working in cab | Maint |
| 21 | Switch decals need replacing | Maint |
| 22 | Both doors have a large amount of rust | Maint |
| 23 | RHS door hinges are worn badly | Maint |
| | Engine air filter housing rusted badly | Maint |
| | Cab locks are sized | Maint |
| 26 | Incorrect alternator belts are fitted | Maint |
| 27 | Turbo oil drain leaking | Maint |
| 28 | Engine ancillary drive bearings need replacing ASAP as this should have been done at 6000HRS | Maint |
| | Heater stepping motor not working | Maint |
| | Oil leak from front of sump / suction hose | Maint |
| 31 | Intercooler needs removing and cleaning | Maint |
| 32 | Bad air leak around air dryer and the compressor is working harder that it should | Maint |
| 33 | Air leaking from module control valve / supply | Maint |
| | One air over electric solenoid has been disconnected ????? | Maint |
| 35 | ROPS hyd jack need new pins/bolts | Maint |
| | Rear guards are damaged and mountings are rusted | Ops |
| | Rear tow pin is seized in | Maint |
| | Rear steers are bent and cracked | Maint |
| 39 | Front end need a wheel alignment (just tow in-out) | Maint |
| | Steering pivots are worn badly | Maint |

| 41 Hyd motor for water pump is leaking oil | Maint |
|--|-------|
| 42 4 drive shafts need rebushing | Maint |
| 43 Steering box leaking | Maint |
| 44 ABS not working on pos 4 as wiring is cut | Maint |
| 45 Transport clamps are still on the spring packs (this will cause them to brake faster) | Maint |
| 46 Bad air leak around first rear axle | Maint |
| 47 POSS 5 backing plates are rusted badly and the rest are missing the rubber covers | Maint |
| 48 Telma needs to be striped and cleaned then tested and not working on all stages | Maint |
| 49 Brake lines have hose clamps on them and this is dangerous | Maint |
| 50 Front 8x8 cyd is disconnected | Maint |
| 51 Pos 1 and 2 steering ball joints are U/S | Maint |
| 52 No tail lights on the lower lights | Maint |
| 53 All tool box latches are U/S | Maint |
| 54 Rear diff drain plug is leaking badly | Maint |
| 55 Module mounting springs have been over tightened and need replacing | Maint |
| 56 RHR Water spray is not working | Maint |
| | |